CONTENTS

1 General Information	5
1.1 / Safety Instructions	5
1.2 Measuring Conditions	5
1.3 Switching the Operating Voltage 230 V~/115 V~	6
1.4 Mains Connection	6
1.5 Installing the RLC 300	6
1.6 Switching on	7
1.7 EMC	7
1.8 Inspection and Maintenance	7
1.9 Warranty	7
1 10 Accessories Supplied	7
1.10 Accessories Supplied	,
2 Application	9
3 Configuration and Functional Description	10
3.1 Block Diagram	10
3.2 Description	11
4 Technical Data	12
4.1 General Data	12
4.2 Specifications	12
4.2.1 Measuring Functions	12
4.2.2 Operating Parameters	13
4.2.3 Measuring Signal Parameters	13
4.2.4 Measuring Kanges	14
4.2.5 1 Measuring Errors during /7/ R L C Measurement	14
4.2.5.2 Measuring Errors during D Measurement	14
4.2.5.3 Measuring Errors during O Measurement	15
4.2.5.4 Measuring Errors during φ Measurement	15
4.2.5.5 Additional Errors and Coefficients	16
4.3 Display	17
4.4 System Interfaces	17
4.4.1 Interface GPIB	17
4.4.2 Interface RS-232C	17
4.4.2.1 Plug Connections of Cable	18
5 Instrument Setting	19
5.1 Connection of the Measured Objects	19
5.2 Control Elements	20

5.3 Starting	22
6 Operation of the RLC 300	24
6.1 Introduction	24
6.2 Measuring Signal Parameters	24
6.2.1 Frequency of the Measuring Signal	24
6.2.1.1 Setting the Frequency	24
6.2.2 Level of the Measuring Signal	25
6.2.2.1 Setting the Level	25
6.2.3 Polarization Voltage	26
6.2.3.1 Setting the Polarization Voltage	26
6.3 Measuring Functions	27
6.3.1 Automatic Measurement of the Main Parameters	27
6.3.1.1 Performing the Automatic Measurement	27
6.3.2 Specific Measurement of the Impedance Parameters	28
6.3.2.1 Performing the Specific Measurement	28
6.3.3 I olerance Measurement	29
6.3.3.2 Parforming the Tolerance Measurement	29
0.5.5.2 I erjorming the Tolerance Measurement	55
6.4 Operating Parameters	36
6.4.1 Selection of the Equivalent Circuit of the Measured Object	36
6.4.2 Measuring Range Selection	37
6.4.2.1 Setting the Measuring Range	38
6.4.2.2 Error Messages	38
6.4.3 Residual Parameters of the Measuring Terminals	39
6.4.3.1 Measuring the Residual Parameters	40
6.4.3.2 Correcting the Residual Parameters	41
6.4.4 Trigger Function	41
6.4.4.1 Setting the Trigger Mode	42
6.4.5 Averaging Function	42
6.4.5.1 Switching on/off the Averaging Function	43
6.5 Additional Functions	44
6.5.1 Monitor Function	44
6.5.1.1 Measuring and Displaying the Measuring Signal Parameters	44
6.5.1.2 Measuring and Displaying the Polarization Voltage	45
6.5.2 User Functions	45 45
6.5.2.1 Saving the Current Instrument Setting	45 47
6.5.2.3 Switching on/off the Initialization Test	47
6.5.2.4 Settings at the Display	48
6.5.3 Service Functions	49
6.5.3.1 Self-diagnosis of the RLC 300	50
6.5.3.2 Special Functions of the RLC 300	50
7 Remote Control by Program	51
7.1 Remote Control via GPIB (IEEE 488.2)	51
7.1.1 Connection of the RLC 300 to the System	51

7.1.2 Selection of the Interface Type 51 7.1.3.1 Interface Parameters 52 7.1.3.1 Setting the GPIB Address 52 7.1.3.2 Operation without Control Unit - TON 52 7.2 Remote Control via RS-232C 53 7.2.1 Connection of the Interface Type 53 7.2.2 Selection of the Interface Type 53 7.2.3 Interface Parameters 53 7.2.3 Interface Parameters 53 7.2.3 Setting the Transmission Protocol 55 7.2.4 Transmission Protocol 55 7.2.4 Transmission Protocol 55 7.2.4.1 Communication without RTS/CTS Protocol 55 7.3 Local Control ⇔ Remote Control 56 7.4.1 Description of the Unit Status 57 7.4.1 Description of Errors 59 7.4.1.2 STB - STATUS BYTE REGISTER 58 7.4.2.2 Error Messages 60 7.4.2.2 Error Messages 60 7.5.1 General Commands 62 7.5.1.2 Initializing the Instrument Settings 63 7.5.1.3 Initializing the Instrument Settings 63 7.5.1.4 Identification of the RLC 300 63 7.5.1.5 Specific Measurement of the		
7.1.3 Interface Parameters527.1.3.1 Setting the GPIB Address527.1.3.2 Operation without Control Unit - TON527.2.3 Remote Control via RS-232C537.2.1 Connection of the RLC 300 to the PC537.2.2 Selection of the Interface Type537.2.3 Interface Parameters537.2.3.1 Setting the Baud Rate547.2.3.2 Setting the Transmission Protocol557.2.4.1 Communication with RTS/CTS Protocol557.2.4.1 Communication with RTS/CTS Protocol557.2.4.2 Communication with RTS/CTS Protocol557.3 Local Control ⇔ Remote Control567.4.1 Description of the Unit Status577.4.1.1 ESR - EVENT STATUS REGISTER587.4.1.2 STB - STATUS BTE REGISTER587.4.2.2 Error Messages607.4.2.2 Error Messages607.5.1.1 Interface Commands627.5.1.2 Interface Commands627.5.1.3 Interface Strumment Settings637.5.1.4 Interface Commands627.5.1.5 Initializing the Instrument Settings637.5.1.6 Signalizing of the RLC 300637.5.1.7 Query of the Instrument Status647.5.2.2 Levels of the Measuring Signal647.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Main Parameters657.5.2.6 Automatic Measuring Range Selection667.5.2.10 Residual Marging Range Selection667.5.2.11 Monitation of the RLC 300677.5.2.12 Notatic Sign	7.1.2 Selection of the Interface Type	51
7.1.3.1 Setting the GPIB Address 52 7.1.3.2 Operation without Control Unit - TON 52 7.2 Remote Control via RS-232C 53 7.2.1 Connection of the RLC 300 to the PC 53 7.2.2 Selection of the Interface Type 53 7.2.3 Interface Parameters 53 7.2.3.1 Setting the Baud Rate 54 7.2.3.2 Setting the Transmission Protocol 55 7.2.4.1 Communication with RTS/CTS Protocol 55 7.2.4.2 Communication with RTS/CTS protocol 55 7.2.4.2 Communication with MTS/CTS protocol 56 7.4.1 Costription of the Unit Status 57 7.4.1 Costription of the Unit Status 57 7.4.1 ESR - EVENT STATUS REGISTER 57 7.4.1 DESCription of the Rote Control 57 7.4.2 DEScription of the Rote Remote Control 58 7.4.2 DEScription of the Rote Status 57 7.4.1 DESCription of the Rote Status 57 7.4.2.2 Error Messages 60 7.5.1.4 Enert Ocumands 62 7.5.1.5 Initializing the Instrument Settings 62 7.5.1.4 Identification of the RLC 300 63 7.5.1.5 Instrument Settings 63 <	7.1.3 Interface Parameters	52
7.1.3.2 Operation without Control Unit - TON 52 7.2 Remote Control via RS-232C 53 7.2.1 Connection of the RLC 300 to the PC 53 7.2.2 Selection of the Interface Type 53 7.2.3 Interface Parameters 53 7.2.4 Transmission Protocol 55 7.2.4.1 Communication with RTS/CTS Protocol 55 7.2.4.2 Communication without RTS/CTS Protocol 55 7.3 Local Control ⇔ Remote Control 56 7.4.1 Description of the Unit Status 57 7.4.1 Description of the Unit Status 57 7.4.1.1 ESR - EVENT STATUS REGISTER 58 7.4.2 Description of Errors 59 7.4.2.1 DER - DEVICE ERROR REGISTER 60 7.5.1.1 Interface commands 62 7.5.1.2 Initializing the Instrument Settings 63 7.5.1.3 Self-Diagnosis of the RLC 300 63 7.5.1.4 Identification of the RLC 3	7.1.3.1 Setting the GPIB Address	52
7.2 Remote Control via RS-232C 53 7.2.1 Connection of the RLC 300 to the PC 53 7.2.2 Selection of the Interface Type 53 7.2.3 Interface Parameters 53 7.2.4 Transmission Protocol 55 7.2.4 Transmission Protocol 55 7.2.4.1 Communication with RTS/CTS Protocol 55 7.3 Local Control ⇔ Remote Control 56 7.4.1 Description of the Unit Status 57 7.4.1 DESC TS D'STAU'S BYTE REGISTER 58 7.4.2 Description of Errors 59 7.4.2.1 DEN - DEVICE ERROR REGISTER 60 7.4.2.2 Error Messages 60 7.5.1.1 Interface commands 62 7.5.1.2 Uritalizing the Instrument Settings 63 7.5.1.3 Self-Diagnosis of the RLC 300 63 7.5.1.4 Identification of the RLC 300 63 7.5.1.5 Specific Measurement of the Main Parameters 65 7.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object 66	7.1.3.2 Operation without Control Unit - TON	52
7.2.1 Connection of the RLC 300 to the PC537.2.2 Selection of the Interface Type537.2.3 Interface Parameters537.2.3.1 Setting the Baud Rate547.2.3.2 Setting the Baud Rate547.2.3.2 Setting the Transmission Protocol557.2.4.1 Communication with RTS/CTS Protocol557.2.4.2 Communication with RTS/CTS protocol557.2.4.1 Communication with RTS/CTS protocol567.3 Local Control \Leftrightarrow Remote Control567.4 Messages of the RLC 300 on Remote Control577.4.1 Description of the Unit Status577.4.1.1 ESR - EVENT STATUS REGISTER577.4.1.2 STB - STATUS BYTE REGISTER587.4.2.1 DER - DEVICE ERROR REGISTER597.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.5.1.1 Interface commands627.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.2.1 Frequency of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measuring Range Selection667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.8 Automatic Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Montior Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement	7.2 Remote Control via RS-232C	53
7.2.2 Selection of the Interface Type 53 7.2.3 Interface Parameters 53 7.2.3.1 Setting the Baud Rate 54 7.2.3.2 Setting the Transmission Protocol 55 7.2.4.1 Communication with RTS/CTS Protocol 55 7.2.4.2 Communication with RTS/CTS protocol 55 7.3 Local Control ⇔ Remote Control 56 7.4.1.0 Excription of the Unit Status 57 7.4.1.1 ESR - EVENT STATUS REGISTER 57 7.4.1.1 ESR - EVENT STATUS REGISTER 57 7.4.1.2 STB - STATUS BYTE REGISTER 59 7.4.2.2 Error Messages 60 7.4.2.1 DER - DEVICE ERROR REGISTER 60 7.4.2.1 DER - DEVICE ERROR REGISTER 60 7.5.1.3 eneral Commands 62 7.5.1.4 Interface commands 62 7.5.1.3 Linitializing the Instrument Settings 63 7.5.1.4 Interface Commands 62 7.5.1.5 Initializing the Brore Register 63 7.5.1.6 Synchronization Commands 63 7.5.1.6 Synchronization Commands 63 7.5.1.6 Synchronization Voltage 65 7.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object 65	7.2.1 Connection of the RLC 300 to the PC	53
7.2.3 Interface Parameters537.2.3 Interface Parameters537.2.3.1 Setting the Baud Rate547.2.3.2 Setting the Transmission Protocol557.2.4.1 Communication with RTS/CTS Protocol557.2.4.2 Communication with NUSY/CTS Protocol557.2.4.2 Communication without RTS/CTS protocol557.3 Local Control \Leftrightarrow Remote Control567.4.1 Description of the Unit Status577.4.1 Description of the Unit Status577.4.1 Description of the Unit Status577.4.2 Description of the Terros597.4.2 Description of the Terros597.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.5.1 General Commands627.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands647.5.2.1 Frequency of the Masuring Signal647.5.2.1 Frequency of the Masuring Signal647.5.2.2 Naturment Settings and Messages647.5.2.3 Polarization Voltage657.5.2.4 Automatic Selection of the Equivalent Circuit of the Measured Object7.5.2.1 Requency of the Masuring Signal647.5.2.1 Prequency of the Instrument Setting677.5.2.1 Intensitie Measuring Range Selection667.5.2.1 Automatic Measurement of the Main Parameters657.5.2.1 Automatic Measurement of the Mas	7.2.2 Selection of the Interface Type	53
7.2.3.1 Setting the Baud Rate547.2.3.2 Setting the Transmission Protocol557.2.4 Transmission Protocol557.2.4.1 Communication with RTS/CTS Protocol557.2.4.2 Communication with RTS/CTS protocol557.3 Local Control \Leftrightarrow Remote Control567.4.1 Description of the Unit Status577.4.1.1 ESR - EVENT STATUS REGISTER577.4.1.2 STB - STATUS BYTE REGISTER587.4.1.2 STB - STATUS BYTE REGISTER597.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.5.1.4 Description of Errors597.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Linitalizing the Instrument Settings627.5.1.3 General Commands627.5.1.4 Interface commands627.5.1.5 Initializing the Instrument Settings637.5.1.6 Synchronization Commands637.5.1.7 Query of the Massages647.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Impedance Parameters657.5.2.5 Specific Measurement of the Ruce Control667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.1 Naturament Settings and Messages647.5.2.2 Lowels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measuring Range Selection667.5.2.1 Manual Selection of the Equivalent Circ	7.2.3 Interface Parameters	53
7.2.3.2 Setting the Transmission Protocol557.2.4.1 Transmission Protocol557.2.4.1 Communication with RTS/CTS Protocol557.2.4.2 Communication without RTS/CTS protocol557.3 Local Control \Leftrightarrow Remote Control567.4.1 Description of the Unit Status577.4.1.1 ESR - EVENT STATUS REGISTER577.4.1.2 STB - STATUS BYTE REGISTER587.4.2 Description of Errors597.4.2.1 DESC - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.5.1.3 Initializing the Instrument Settings627.5.1.3 Initializing the Error Register637.5.1.3 Initializing the Error Register637.5.1.7 Query of the Instrument Status647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Commands657.5.2.4 Automatic Selection of the Equivalent Circuit of the Measured Object7.5.2.5 Specific Measurement of the Main Parameters657.5.2.6 Automatic Selection667.5.2.1 Instrument Setting Range Selection667.5.2.2 Levels of the Measuring Range Selection667.5.2.3 Polarization Othe Equivalent Circuit of the Measured Object667.5.2.1 Resurement of the Main Parameters657.5.2.1 Instrument Getting Range Selection667.5.2.1 Resurement of the Main Parameters657.5.2.2 Specific Measurement of the Main Parameters657.5.2.1 Resurement of the Main Parameters657.5.2.1 Instrument Resurement of the Measuring Terminals677.5.2	7.2.3.1 Setting the Baud Rate	54
7.2.4 Transmission Protocol557.2.4.1 Communication with RTS/CTS Protocol557.2.4.2 Communication without RTS/CTS protocol557.3 Local Control \Leftrightarrow Remote Control567.4.1 Description of the Unit Status577.4.1 Description of the Unit Status577.4.1.2 STB - STATUS REGISTER577.4.2 Description of Errors597.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.5.1 General Commands627.5.1.3 Interface commands627.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Instrument Settings637.5.1.6 Synchronization Commands637.5.1.7 Query of the Macro Register637.5.2.1 Frequency of the Massages647.5.2.1 Frequency of the Massages647.5.2.2 Levis of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measuring Signal647.5.2.5 Specific Measuring Range Selection667.5.2.6 Automatic Measuring Range Selection667.5.2.11 Monitor Function677.5.2.12 Initializing the Error Register657.5.2.5 Automatic Measuring Range Selection667.5.2.6 Automatic Measuring Range Selection667.5.2.7 Specific Measuring Range Selection667.5.2.11 Monitor Function677.5.2.13 Tolerance Measurement677.5.2.14 Integer Function677.5.2.15 Automatic Measurement677.5.2.14 Intege	7.2.3.2 Setting the Transmission Protocol	55
7.2.4.1 Communication with RTS/CTS Protocol557.2.4.2 Communication without RTS/CTS protocol557.3 Local Control \Leftrightarrow Remote Control567.4 Messages of the RLC 300 on Remote Control577.4.1 Description of the Unit Status577.4.1.1 ESR - EVENT STATUS REGISTER577.4.1.2 STB - STATUS BYTE REGISTER587.4.2.1 DER - DEVICE ERROR REGISTER597.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.5.1.3 General Commands627.5.1.4 Identification of the RLC 300637.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands647.5.2.1 Frequency of the Instrument Status647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measuring Signal647.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Measuring Range Selection667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Automatic Measurement677.5.2.14 Automatic Measurement677.5.2.15 Automatic Measurement677.5.2.14 Automatic Measurement of the Main Parameters657.5.2.2 Manual Selection of the Equivalen	7.2.4 Transmission Protocol	55
7.2.4.2 Communication without RTS/CTS protocol 55 7.3 Local Control ⇔ Remote Control 56 7.4.1 Description of the Unit Status 57 7.4.1 Description of the Unit Status 57 7.4.1 Description of the Unit Status 57 7.4.1 DESCRIPTION SPITE REGISTER 57 7.4.1 STB - STATUS BYTE REGISTER 59 7.4.1 DESCRIPTION DETORS 59 7.4.2.1 DER - DEVICE ERROR REGISTER 60 7.4.2.2 Error Messages 60 7.5.1.3 General Commands 62 7.5.1.4 Interface commands 62 7.5.1.5 Initializing the Instrument Settings 63 7.5.1.4 Identification of the RLC 300 63 7.5.1.5 Initializing the Error Register 63 7.5.1.6 Synchronization Commands 63 7.5.2.1 Frequency of the Measuring Signal 64 7.5.2.1 Frequency of the Measuring Signal 64 7.5.2.2 Levels of the Measuring Signal 64 7.5.2.3 Polarization Voltage 65 7.5.2.4 Automatic Measurement of the Impedance Parameters 65 7.5.2.5 Specific Measurement of the Equivalent Circuit of the Measured Object 66 7.5.2.1 Monuiar Selection of	7.2.4.1 Communication with RTS/CTS Protocol	55
7.3 Local Control ⇔ Remote Control 56 7.4.1 Description of the Unit Status 57 7.4.1.1 ESR - EVENT STATUS REGISTER 57 7.4.1.2 STB - STATUS BYTE REGISTER 58 7.4.2.2 Description of Errors 59 7.4.2.1 DER - DEVICE ERROR REGISTER 60 7.4.2.2 Error Messages 60 7.5.1 General Commands on Remote Control 62 7.5.1.3 tof Commands on Remote Control 62 7.5.1.4 Interface commands 62 7.5.1.5 List of Commands 62 7.5.1.4 Interface commands 62 7.5.1.5 Initializing the Instrument Settings 63 7.5.1.6 Synchronization Commands 63 7.5.1.7 Query of the RLC 300 63 7.5.1.6 Synchronization Commands 64 7.5.2.1 Instrument Settings and Messages 64 7.5.2.1 Frequency of the Measuring Signal 64 7.5.2.3 Polarization Voltage 65 7.5.2.4 Automatic Measurement of the Impedance Parameters 65 7.5.2.5 Automatic Measuring Range Selection 66 7.5.2.1 Manual Selection of the Equivalent Circuit of the Measured Object 66 7.5.2.1 Renauel Measuring Range Selection	7.2.4.2 Communication without RTS/CTS protocol	55
7.4 Messages of the RLC 300 on Remote Control577.4.1 Description of the Unit Status577.4.1.1 ESR - EVENT STATUS REGISTER577.4.1.2 STB - STATUS BYTE REGISTER587.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.5.1 General Commands627.5.1.1 Interface commands627.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands637.5.1.7 Query of the Instrument Status647.5.2.1 Frequency of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Automatic Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.12 Naturatic Measuring Range Selection667.5.2.13 Tolerance Measuring Range Selection677.5.2.14 Trigger Function677.5.2.15 Saving and Loading of the Instrument Setting677.5.2.14 Trigger Function677.5.2.15 Lawing and Loading of the Instrument Setting677.5.2.14 Trigger Function677.5.2.15 Zaving and Loading of the Instrument Setting677.5.2.15 Zaving and Loading of the Instrument Setting677.5.2.15 Saving and Load	7.3 Local Control ⇔ Remote Control	56
7.4.1 Description of the Unit Status577.4.1.1 ESR - EVENT STATUS REGISTER577.4.1.2 STB - STATUS BYTE REGISTER587.4.2.2 Description of Errors597.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.4.2.2 Error Messages607.5.1 General Commands627.5.1.1 Interface commands627.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.7 Query of the Instrument Status647.5.2.1 Frequency of the Measuring Signal647.5.2.1 Specific Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Equivalent Circuit of the Measured Object667.5.2.10 Residual Parameters of the Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Range Selection667.5.2.11 Requered for the Measuring Range Selection677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function677.5.2.15 Saving and Loading of the Instrument Setting697.5.2.15 Saving and Loading of the Instrument Setting697.5.3.17 Measurement of the Main Parameters677.5.3.17 Tansmitting the Results707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tole	7.4 Messages of the RLC 300 on Remote Control	57
7.4.1.1 ESR - EVENT STATUS REGISTER577.4.1.2 STB - STATUS BYTE REGISTER587.4.2.1 DER - DEVICE ERROR REGISTER597.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.5.1 General Commands on Remote Control627.5.1.1 Interface commands627.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Instrument Settings637.5.1.6 Synchronization Commands637.5.2.1 Frequency of the Instrument Status647.5.2.1 Frequency of the Massages647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function677.5.2.15 Saving and Loading of the Instrument Setting697.5.2.16 Interance Measurement677.5.2.17 Dearance Measurement677.5.2.18 Automatic Measurement677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3.1 Tensentiting the Results707.	7.4.1 Description of the Unit Status	57
7.4.1.2 STB - STATUS BYTE REGISTER587.4.2 Description of Errors597.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.4.2.2 Error Messages607.5.1 General Commands on Remote Control627.5.1.1 Interface commands627.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands647.5.2.1 Frequency of the Instrument Status647.5.2.3 Polarization Commands657.5.2.4 Automatic Measuring Signal647.5.2.5 Specific Measurement of the Main Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.8 Automatic Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function677.5.2.15 Saving and Loading of the Instrument Setting697.5.3.17 Delarance Measurement677.5.3.17 Term677.5.3.2 Tolerance Measurement677.5.3.2 Tolerance Measurement677.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2	7 4 1 1 ESR - EVENT STATUS REGISTER	57
7.4.2 Description of Errors597.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.5.1.3 Error Messages607.5.1.4 Interface commands627.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands647.5.2.1 Frequency of the Instrument Status647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function677.5.2.15 Saving and Loading of the Instrument Setting697.5.3.14 Trigger Function677.5.3.2 Tolerance Measurement677.5.3.2 Tolerance Measurement777.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement70	7 4 1 2 STR - STATUS RYTE REGISTER	58
7.4.2.1 DER - DEVICE ERROR REGISTER607.4.2.2 Error Messages607.5.1 General Commands627.5.1.3 Interface commands627.5.1.4 Interface commands627.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands637.5.1.7 Query of the Instrument Status647.5.2.1 Frequency of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function677.5.2.15 Saving and Loading of the Instrument Setting697.5.3.10 Residual Parameters677.5.3.2 Tolerance Measurement677.5.3.3 Transmitting the Results707.5.3.4 Tolerance Measurement777.5.3.2 Tolerance Measurement777.5.3.2 Tolerance Measurement777.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement70	7 4 2 Description of Friors	59
7.4.2.2 Error Messages607.4.2.2 Error Messages607.5.1 List of Commands on Remote Control627.5.1.6 General Commands627.5.1.1 Interface commands627.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands637.5.1.7 Query of the Instrument Status647.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.5 Specific Measurement of the Main Parameters657.5.2.6 Automatic Measurement of the Impedance Parameters657.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3.17 Measurement of the Instrument Setting697.5.2.15 Saving and Loading of the Instrument Setting707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement70 <tr <tr="">707.5.3.2 Tolerance M</tr>	7 4 2 1 DER - DEVICE ERROR REGISTER	60
7.5 List of Commands on Remote Control627.5.1 General Commands627.5.1.1 Interface commands627.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands637.5.1.7 Query of the Instrument Status647.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.5 Specific Measurement of the Main Parameters657.5.2.6 Automatic Measurement of the Impedance Parameters657.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3.17 Tansmitting the Results707.5.3.2 Tolerance Measurement707.5.3.2 To	7.4.2.2 Error Messages	60
7.5.1 Store601627.5.1 General Commands627.5.1.1 Interface commands627.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands637.5.1.7 Query of the Instrument Status647.5.2.1 Frequency of the Instrument Status647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.3.15 Measurement of the Instrument Setting697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	751 ist of Commands on Remote Control	62
7.5.1.1 Interface commands627.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands637.5.1.7 Query of the Instrument Status647.5.2 Instrument Settings and Messages647.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function677.5.2.15 Saving and Loading of the Instrument Setting697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.1 General Commands	62
7.5.1.1 Interface community637.5.1.2 Initializing the Instrument Settings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands637.5.1.7 Query of the Instrument Status647.5.2 Instrument Settings and Messages647.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function677.5.2.15 Saving and Loading of the Instrument Setting697.5.3.1 Measurement of the Main Parameters707.5.3.1 Measurement of the Instrument Setting707.5.3.2 Tolerance Measurement70	7.5.1 1 Interface commands	62
7.5.1.2 Initializing the Influence Dollings637.5.1.3 Self-Diagnosis of the RLC 300637.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands637.5.1.7 Query of the Instrument Status647.5.2 Instrument Settings and Messages647.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.3.15 Saving and Loading of the Instrument Setting697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.1.7 Interface commands 7.5.1.2 Initializing the Instrument Settings	63
7.5.1.4 Identification of the RLC 300637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands637.5.1.7 Query of the Instrument Status647.5.2 Instrument Settings and Messages647.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.3.1 Tansmitting the Results707.5.3.1 Measurement of the Instrument Setting707.5.3.2 Tolerance Measurement70	7 5 1 3 Self-Diagnosis of the RLC 300	63
7.5.1.1 Intentification of the Recood637.5.1.5 Initializing the Error Register637.5.1.6 Synchronization Commands637.5.1.7 Query of the Instrument Status647.5.2.1 Instrument Settings and Messages647.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.1.3 Set Diagnosis of the RLC 300	63
7.5.1.6 Synchronization Commands637.5.1.6 Synchronization Commands647.5.1.7 Query of the Instrument Status647.5.2 Instrument Settings and Messages647.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting707.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7 5 1 5 Initializing the Error Register	63
7.5.1.7 Query of the Instrument Status647.5.2 Instrument Settings and Messages647.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7 5 1 6 Synchronization Commands	63
7.5.2 Instrument Settings and Messages647.5.2.1 Frequency of the Measuring Signal647.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.1.7 Query of the Instrument Status	64
7.5.2.1 Frequency of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.8 Automatic Measuring Range Selection667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.3.1 Measurement of the Instrument Setting697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement70	7.5.2 Instrument Settings and Messages	64
7.5.2.2 Levels of the Measuring Signal647.5.2.2 Levels of the Measuring Signal647.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.8 Automatic Measuring Range Selection667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement70	7.5.2.1 Frequency of the Measuring Signal	64
7.5.2.3 Polarization Voltage657.5.2.3 Polarization Voltage657.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.8 Automatic Measuring Range Selection667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.3.1 Measurement of the Instrument Setting697.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement70	7.5.2.2 Levels of the Measuring Signal	64
7.5.2.4 Automatic Measurement of the Main Parameters657.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.8 Automatic Measuring Range Selection667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement70	7.5.2.3 Polarization Voltage	65
7.5.2.5 Specific Measurement of the Impedance Parameters657.5.2.5 Specific Measurement of the Equivalent Circuit of the Measured Object667.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.8 Automatic Measuring Range Selection667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement707.5.3.1 Description70	7.5.2.4 Automatic Measurement of the Main Parameters	65
7.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object667.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.8 Automatic Measuring Range Selection667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement707.5.3.2 Tolerance Measurement70	7.5.2.5 Specific Measurement of the Impedance Parameters	65
7.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object667.5.2.8 Automatic Measuring Range Selection667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.2.6 Automatic Selection of the Equivalent Circuit of the Measured Object	66
7.5.2.8 Automatic Measuring Range Selection667.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object	66
7.5.2.9 Manual Measuring Range Selection667.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3 Transmitting the Results707.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.2.8 Automatic Measuring Range Selection	66
7.5.2.10 Residual Parameters of the Measuring Terminals677.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3 Transmitting the Results707.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.2.9 Manual Measuring Range Selection	66
7.5.2.11 Monitor Function677.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3 Transmitting the Results707.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.2.10 Residual Parameters of the Measuring Terminals	67
7.5.2.12 Averaging function677.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3 Transmitting the Results707.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.2.11 Monitor Function	67
7.5.2.13 Tolerance Measurement677.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3 Transmitting the Results707.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.2.12 Averaging function	67
7.5.2.14 Trigger Function697.5.2.15 Saving and Loading of the Instrument Setting697.5.3 Transmitting the Results707.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.2.13 Tolerance Measurement	67
7.5.2.15 Saving and Loading of the Instrument Setting697.5.3 Transmitting the Results707.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.2.14 Trigger Function	69
7.5.3 Transmitting the Results707.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.2.15 Saving and Loading of the Instrument Setting	69
7.5.3.1 Measurement of the Main Parameters707.5.3.2 Tolerance Measurement70	7.5.3 Transmitting the Results	70
7.5.3.2 Tolerance Measurement 70	7.5.3.1 Measurement of the Main Parameters	70
	7.5.3.2 Tolerance Measurement	70

7.5.3.3 Measuring Parameters at Active Monitor Function	71
7.6 Programming Notes	72
7.7 Program Examples (Q Basic)	73
7.7.1 Remote Control via Interface GPIB	73
7.7.2 Remote Control via Interface RS-232C	74
8 Maintenance	75
9 Appendix	76
9.1 List of all Instrument Messages	76
9.2 Declaration of Conformity	77

1 General Information

1.1 A Safety Instructions

Ē	Note	Wherever you see this sign \bigwedge you will find information on potential hazards. Please read these sections with particular care!
\triangle	Warning!	Before opening the RLC 300 disconnect the mains plug!
	Attention!	Our instrument fuses are dimensioned in such a way that optimum protection is guaranteed for the instrument and the user. In industrial power supplies, which are extremely strongly loaded, the instrument fuses could respond sporadically due to high voltage peaks. If the fuse has to be changed, use only G fuse-link 5×20 according to IEC 127 (See p. 12, Para. 4.1)!
\triangle	Attention!	The replacement fuses T125 contained in the accessories are determined for a mains voltage of 115 V and may not be used at mains voltage of 230 V!
1.2	Measuring Con	ditions
\triangle	Attention!	Direct or alternating voltages and direct or alternating currents must not be connected to the measuring sockets of the RLC 300.
\triangle	Attention!	Capacitors must be discharged before connection to the measuring sockets. If not, the RLC 300 could be damaged!
\triangle	Attention!	The maximum admissible limit of the external polarization voltage $V_{max} = 30$ V at the BIAS sockets must not be exceeded. Take note of the polarity of the external polarization voltage.

1.3 A Switching the Operating Voltage 230 V~/115 V~

Note

Setting the operating voltage 115 V~

Mains voltage

switch

Your RLC 300 left the factory set to 230 V \sim . Switching to 115 V \sim requires the RLC 300 to be opened, which should only be done by trained personnel.

- 1. Disconnect the RLC 300 from the mains.
- 2. Remove upper caps and loosen the screws below.
- **3.** Identify the mains voltage switch with the following illustration.
- **4.** Switch the mains voltage switch (slide switch) located under the power switch to the indication "115".
- **5.** Remove safety cover at the mains plug and replace the fuse with the fuse for 115 V supplied with the instrument.
- 6. Fasten upper caps and put the sticker supplied with the instrument for marking the switch-over to 115 V on to the type label.





115 V position

230 V position

1.4 A Mains Connection

ProtectiveThe design of the unit meets the requirements of safety class I
according to EN 61010-1.

Power is supplied via a mains cable with earthing contact.

1.5 Installing the RLC 300

Attention! Dewfall can cause damage at the RLC 300. If the RLC 300 was stored in a cold surrounding, allow it to acclimatize at room temperature.

The RLC 300 should not be operated close to equipment that develops heat.

The ventilation slots on the case of the RLC 300 must not be covered and no liquid may enter.

1.6 Switching on

Note	The RLC 300 is switched on using the power switch at the front. The power switch separates the RLC 300 completely from the primary side of the transformer. The LED <i>I/O</i> serves as a status indicator.	
1.7 EMC		
Interference suppression	The RLC 300 is interference-free according to the EN 55011 Class B in agreement with the recommendations IEC CISPR No. 34.	
Prerequisite for EMC	 In order to fulfil the limiting values in line with present standards, it is absolutely essential that only cables which are in perfect condition be connected to the unit. The following information applies here: After opening and closing the RLC 300 check that all the fixing elements are installed as before and that all the screws have been tightened. 	

1.8 Inspection and Maintenance

Note

If service is needed, due attention should be paid to the regulations according to VDE 0701. The RLC 300 should only be repaired by trained personnel.

1.9 Warranty

Conditions for warranty	<i>digimess</i> guarantees the perfect working order of the RLC 300 for 12 months as from delivery. There is no warranty for faults arising from improper operation or from changes made to the unit or from inappropriate application.				
Returning the RLC 300	If a fault occurs please contact or send your RLC 300 to:				
	The RLC 300 should be returned in appropriate packing - if possible in the original packing. Please enclose a detailed fault report (functions working incorrectly, deviating specifications and so on) including unit type and serial number.				
Identification	Kindly verify warranty cases by enclosing your delivery note. Any repairs carried out without reference to a valid warranty will initially be at the owner's expense. Should the warranty have expired, we will, of course, be glad to repair your RLC 300 as per our General Terms Of Assembly And Service.				

1.10 Accessories Supplied

Contents	1 mains cable			
	1 fine-wire fuse	T100L250V (230 V~)		
	2 fine-wire fuses	T200L250V (115 V~)		
	1 four-terminal configuration	1 four-terminal configuration RLC adapter for radial and axial		
	components			

- 1 SMD adapter
- 1 adapter with Kelvin terminals
- 1 measuring earth cable
- 1 operating instructions
- 1 label for indicating the switch-over to 115 $\rm V$

2 Application

Performance features	 The automatic RLC 300 is a microprocessor-controlled measuring instrument for precise and fast evaluation of impedance parameters of passive and active components and circuits within a broad measuring range. Basic accuracy is 0.1 %. The frequencies of the internal measuring signal are 50 Hz, 100 Hz, 1 kHz and 10 kHz. Two measuring signal levels can be selected and allow for measurements of components with semiconductor transitions, too. The internal or external polarization voltage can be selected alternatively and serves to measure electrolytic capacitors and semiconductor components.
Connection of the measured object	The objects to be measured are connected to the RLC 300 by a four- terminal configuration with Kelvin terminals and measuring adapters. The effect of stray capacitances, lead inductances and contact resistance is thus substantially reduced. The residual parameters of the measuring terminals can be compensated.
Measuring principle	In response to the connected impedance, the RLC 300 automatically recognises the object being measured and the measuring range and allows the parameters to be determined using the series and parallel equivalent circuit diagram of the object being measured.
Performance features	 The comprehensive equipment level of the RLC 300 ensures a wide range of features: Automatic determination of the object being measured Automatic selection of measuring range Correction of the residual parameters Automatic or manual triggering of the measurements Indication of the measuring voltage, the measuring current or the polarization voltage (monitor function) Increase of the measuring precision (averaging function) Tolerance measurements Comparison measurements User-oriented functions
Operation via RLC 300	All functions and parameters can be set with eight buttons via menus. The chosen parameters and functions as well as the measurements are clearly depicted on a two-line alphanumeric LC matrix display.
Remote control via PC	 The RLC 300 is equipped, as standard, with the interfaces GPIB and RS-232C for communication with a PC. All functions and parameters can be set. Set values and states of the RLC 300 can be transmitted.

3 Configuration and Functional Description

3.1 Block Diagram



Fig. 1 Block diagram of the RLC 300

- (1) Measuring signal generator
- (2) Amplitude control
- (3) Lowpass
- (4) Output amplifier
- (5) Switch for the generation of the polarization voltage
- (6) Amplifier
- (7) Adjustable amplifier
- (8) I/V converter
- (9) Amplifier
- (10) Switchover for the voltage and current channels
- (11) Separation amplifier
- (12) Attenuator
- (13) Amplifier
- (14) Comparator
- (15) Switch for the input signals of the A/D converter
- (16) Voltage amplifier and inverter

- (17) Sync detector
- (18) Integrator
- (19) Amplifier
- (20) Comparator
- (21) Control logic
- (22) Microprocessor
- (23) Source of the reference voltage for the A/D converter
- (24) Timer
- (25) Keyboard
- (26) LCD display
- (27) EPROM memory
- (28) EEPROM memory
- (29) Interfaces GPIB and RS-232C
- (30) Power supply
- (31) Comparator of the analogous overload

3.2 Description

Measuring principle	The measuring impedance Z_X is determined with the help of the voltage at the measured object (impedance Z_X) and from the current passing through the measured object. The vector division of the voltage and the current result in four components. The selected parameters are calculated mathematically from the components.
Supply of the generator signal	The generator signal is defined supplied to the measured object Z_X via the oscillator with amplitude control (1), (2), (3), (4), the separating transformer, and the series resistor R_S .
Picking off the measuring signal	The voltage picked off by the measured object Z_X , is determined directly with the help of the operating amplifier (6). The voltage, which is proportional to the current passing through the measured object Z_X is supplied by the I/V converter (8). The signals are further processed in the component groups (7), (9) and led to the switch (10).
Processing of the measuring signal	The voltage amplification of the component groups (11), (12), (13) is set according to the measured impedance value. The adjusted measuring signal is led to the sync detector (17) via the input circuits of the A/D converter (15), (16). The sync detector evaluates the real and imaginary components of the voltage and current vectors (U_{re} , U_{im} , I_{re} , I_{im}) of the measured object Z_X . The evaluated voltages are transformed by the A/D integration converter.
A/D conversion	A/D conversion takes place with the help of the integrator (18), the amplifier (19), the comparator (20), the control logic (21) and the voltage reference source (23). Synchronisation takes place via the comparator (14). The numeric values of the A/D converter are saved in the internal memory of the microprocessor (22) for further processing.
Determination of the measuring impedance	At the auto mode the error message of the comparator (31) and the numeric overflow of the A/D converter control the measuring range selection after the connection of the measuring impedance Z_X . The microprocessor (22) determines the character of the measuring impedance in response to the phase shift of the voltage and current vectors.
Internal control unit	The internal measuring sequence is controlled by the one-chip microprocessor MCS-51 (22) with the help of additional circuits, e. g., program memory EPROM (27), data memory EEPROM (28) and timer (24).
Operating the RLC 300	The RLC 300 can be operated locally via the keyboard (25) and via the LC display (26). Remote control by a PC takes place via the interfaces GPIB and RS-232C (29).
Power supply	The modules are supplied by the internal power supply (30).

4 Technical Data

4.1 General Data	
Nominal temperature:	$+ 23 \degree C \pm 2 \degree C$
Operating temperature:	+ 5 + 40 °C
Relative humidity:	20 80 %
Atmospheric pressure:	70 106 kPa
Operating position:	horizontal or inclined by \pm 15 $^{\circ}$
Operating voltage:	sinusoidal alternating voltage, distortion factor < 5 % 115/230 V (+ 10 %/– 15 %), internally switchable 47 63 Hz
Power consumption:	max. 20 W
Fuses:	T100L250V (230 V~) T200L250V (115 V~)
Safety class:	I, according to EN 61010 Part 1
Radio interference suppression:	EN 55011 Class B
Dimensions (L \times H \times D):	$291 \text{ mm} \times 120 \text{ mm} \times 259 \text{ mm}$
Dimensions of packing:	$418 \text{ mm} \times 155 \text{ mm} \times 355 \text{ mm}$
Weight of RLC 300: incl. packing and accessories:	approx. 3.5 kg approx. 5.2 kg

4.2 Specifications

4.2.1 Measuring Functions

Measuring parameters:

 $\begin{array}{ll} |\mathbf{Z}| & - \mbox{ absolute value of the impedance (amount)} \\ \mathbf{R} & - \mbox{ resistance} \\ \mathbf{L} & - \mbox{ inductance} \\ \mathbf{C} & - \mbox{ capacity} \\ \mathbf{D} & - \mbox{ dissipation factor} \\ \mathbf{Q} & - \mbox{ quality factor} \\ \mathbf{\phi} & - \mbox{ phase shift} \end{array}$

Combinations of the measuring parameters:

Main parameters	Secondary parameters			
	Measuring function			
	AUTO	MANUAL		
R	Q	Q	D	L, C
L	Q	Q	D	R
С	D	Q	D	R
Z	Z		φ	



Tolerance measurement:	Δ δ COMP	 absolute deviation of the measured value from the entered reference value relative deviation of the measured value from the entered reference value function for sorting the component elements according to set tolerance limits
4.2.2 Operating Parameters		
of the measured object:	series con parallel c	nnection connection
Selection of measuring range:	automatic manual (1	c fixed range)
Selection of measuring function:	automatio manual	2
Triggering of the measurements:	automatic manual (s	c single)
Measuring time:	(valid for measurin approx. 3 approx. 4	r fixed range or after selection of the g range) 600 ms for measuring signal level of 1 V 600 ms for measuring signal level of 50 mV
Averaging:	10 times	
Connection of the measured object:	four-term	inal configuration with ground terminal
Correction of the residual parameters: $10 \ \Omega$)	at short-c	circuit of the measuring terminals ($Z_X <$
	at idling	of the measuring terminals ($Z_X > 100 \text{ k}\Omega$)
Warm-up time:	20 min	

4.2.3 Measuring Signal Parameters

Measuring frequencies:	50 Hz, 100 Hz, 1 kHz, 10 kHz
Levels of the measuring signal:	1 V (normal)
	50 mV (low)
Output impedance:	100 Ω
Polarization of the measured object:	2 V (internal)
	0 30 V (external)

Indication of the measuring signal parameters:

Parameter	Range	Accuracy
Voltage	0.001 mV 1.000 V	$\pm (3 \% + 0.1 \text{ mV})$
Current	0.1 nA 10.00 mA	$\pm (3 \% + 10 \text{ nA})$
BIAS	0 30.00 V	$\pm (1 \% + 10 \text{ mV})$

Table 2	Indication of	the measurin	g signal	parameters
	5		0 0	1

4.2.4 Measuring Ranges

Measuring parameter	Measuring range	Resolution
Z , R	0.01 mΩ 199.9 MΩ	0.01 mΩ
L	0.001 μH 635.5 kH	0.001 µH
С	0.001 pF 399.9 mF	0.001 pF
D	0.0000 9.999	0.0001
Q	0.0000 199	0.0001
φ	- 179.99 ° + 180.00 °	0.01°
δ	- 99.99 % + 199.9 %	0.01 %

Table 3Measuring ranges and resolution of the display values

4.2.5 Measuring Accuracy

The specifications are valid under the following conditions:

• Warm-up time of $t \ge 20$ min

Ab

- Connection of the measured object with supplied measuring adapters (See p. 7, Para. 1.10)
- Max. capacity of $C \le 200 \text{ pF}$ of the measuring sockets Li and Lu against ground
- Correction of the residual parameters of the measuring terminals (See p. 39, Para. 6.4.3)

4.2.5.1 Measuring Errors during /Z/, R, L, C Measurement

• For |Z| measurement and R measurement with $Q_m \le 0.1$ and L/C measurement with $D_m \le 0.1$ the measuring error is the result of the following equation:

$$\mathbf{A} = \pm \left(\mathbf{A}_{\mathbf{b}} + \mathbf{K}_{\mathbf{s}} + \mathbf{K}_{\mathbf{p}} \right) \times \mathbf{K}_{\mathbf{l}} \times \mathbf{K}_{\mathbf{t}} \quad [\%]$$

where:

- basic error (See p. 16, Table 4)
- K_s additional error for low impedances (See p. 16, Table 5)
- **K**_p additional error for high impedances (See p. 16, Table 5)
- **K**_I coefficient of the measuring signal level (See p. 16, Table 6)
- K_t temperature coefficient (See p. 17, Table 7)
- For R measurement with $Q_m > 0.1$ the measuring error results from the product:

$$\mathbf{A} \times \sqrt{\mathbf{1} + \mathbf{Q}_{m}^{2}} \qquad [\%]$$

where: \mathbf{Q}_{m} - measured value of the quality Q

• For L/C measurement with $D_m > 0.1$ the measuring error results from the product:

$$\mathbf{A} \times \sqrt{\mathbf{1} + \mathbf{D}_{\mathbf{m}}^2} \qquad [\%]$$

where: **D**_m

- measured value of the dissipation factor D

• Conversion of the impedance Z with the parameters L and C can be carried out with the nomogram (See p. 16, Table 4) or with the following equations:

$$Z = \omega L$$
 or $Z = \frac{1}{\omega C}$.

4.2.5.2 Measuring Errors during D Measurement

• For D measurement with $D_m \le 0.1$ the measuring error results from the following equation:

 $\pm A_{D}$ / 100 [absolute value D]

• For D measurement with $0.1 < D_m \le 1$ the measuring error results from the product:

$$\pm \frac{A_{\rm D}}{100} \times (1 + D_{\rm m}) \qquad [absolute value D]$$

• For D measurement with $D_m > 1$ the measuring error results from the product:

$$\pm \frac{A_{D}}{100} \times D_{m} \times (1 + D_{m}) \qquad [absolute value D]$$
$$A_{D} = A \times (1 + \frac{f}{10000})$$

where:

 A - measuring error of the main parameter in [%] (See p. 14, Para. 4.2.5.1)
 f - frequency of the measuring signal in [Hz]
 D_m - measured value of the dissipation factor D

4.2.5.3 Measuring Errors during Q Measurement

• For Q measurement with $Q_m \leq 0.1$ the measuring error results from the following equation:

$$\pm A_{D}$$
 /100 [absolute value Q]

• For Q measurement with $0.1 < Q_m \le 1$ the measuring error results from the product:

$$\pm \frac{\mathbf{A}_{\mathsf{D}}}{100} \times (1 + \mathbf{Q}_{\mathsf{m}}) \qquad [absolute value Q]$$

• For Q measurement with $1 < Q_m \le 10$ the measuring error results from the product:

$$\pm \frac{\mathbf{A}_{\mathrm{D}}}{100} \times \mathbf{Q}_{\mathrm{m}} \times (1 + \mathbf{Q}_{\mathrm{m}}) \qquad [absolute value Q]$$

• For Q measurement with $Q_m > 10$ the measuring error results from the product:

$$\pm \frac{A_{\rm D}}{100} \times Q_{\rm m}^2 \qquad [absolute value Q]$$

where: $\mathbf{Q}_{\mathbf{m}}$ - measured value of the quality Q

4.2.5.4 Measuring Errors during φ Measurement

• The measuring error results from the following equation:

$$\frac{180}{\pi} \times \frac{A_{\rm D}}{100} \qquad [deg]$$



4.2.5.5 Additional Errors and Coefficients

Table 4Basic error

Frequency	K _s [%]	K _p [%]
50 Hz	$2 \times \frac{0,1}{ \mathbf{Z}_{\mathbf{m}} }$	$2 \times \mathbf{Z}_{\mathrm{m}} \times 10^{-7}$
100 Hz 10 kHz	$\frac{0,1}{\left \boldsymbol{Z}_{\mathrm{m}}\right }$	$ \mathbf{Z}_{\mathrm{m}} \times 10^{-7}$

where: $|\mathbf{Z}_{\mathsf{m}}|$ - measuring impedance $[\Omega]$



Measuring signal level	NORMAL (1 V)	LOW (50 mV)
Kı	1	2

Table 6Coefficient of the measuring signal level

Temperature [° C]		5 1	1 2	1 2	5 3	5 4	0
K _t	-	2	1.5	1	1.5	2	-

Table 7Temperature coefficient

4.3 Display

The RLC 300 is equipped with a 16-digit alphanumerical LC matrix Set-up and display contents display with background lighting. It indicates measuring results, error messages or the menu-controlled functions and system messages.

4.4 System Interfaces

Performance	The RLC 300 is equipped, as standard, with the interfaces GPIB and
range	RS-232C for communication with a PC. All functions and parameters
	can be set. Set values and states of the RLC 300 can be transmitted.

4.4.1 Interface GPIB

Interface standards:	ANSI/IEEE Std 188 1 1087 and
interface stanuarus.	ANSI/IEEE Siu 400.1-1907 aliu
	IEEE Std 488.2-1992
Interface functions:	SH1, AH1, SR1, T5, L4, RL1, PP0, DC1, DT1, E2
Length of input buffer:	64 characters
Length of output buffer:	256 characters
General commands:	*CLS, *ESE, *ESE?, *ESR?, *SRE, *SRE?, *STB?, *IDN?, *RST, *TST?, *TRG, *OPC, *OPC?, *WAI
4.4.2 Interface RS-232C	
Font:	ASCII
Baud rate (eligible):	1200, 2400, 4800, 9600 Bd
Length of data character:	8 Bit
Number of STOP bits:	1
Parity:	none
Protocol:	RTS/CTS, without (NONE)
Length of input buffer:	64 characters
Length of output buffer:	256 characters
End character on receiving:	LF (10 dec.)
End characters on transmission:	CR + LF (13 dec. + 10 dec.)

4.4.2.1 Plug Connections of Cable



Fig. 2 Plug connections of cable RS-232C

5 Instrument Setting

5.1 Connection of the Measured Objects

P Note

Connecting the measuring cable or the measuring adapter wrongly to the measuring sockets Hi, Hu, Lu, Li leads to incorrect measuring results but not to operational disturbances.

Connecting the measured object with the adapter

Connect the measured object Z_x to the RLC 300 via one of the supplied measuring adapters (See p. 7, Para. 1.10). The effect of the stray capacitances, line inductances and transition resistors is thus strongly reduced.

The measuring sockets are marked with the symbols Hi, Hu, Lu and Li. The ground terminal is used for the galvanic connection between the shield of the measured object which may be needed and the earth of the RLC 300.

Connecting the measured object Should you wish to connect the measured object only via the measuring cable (four-terminal) abide by the measuring directions according to Fig. 3 (See p. 19). Hu and Lu connections must be at the shortest distance possible from the measured object. The shield of the measuring cable must also be connected.



Fig. 3 Connecting the measured object without the adapter

5.2 Control Elements



Fig. 4 Front side of the RLC 300



Fig. 5 Rear side of the RLC 300

- [1] Power switch
- [2] LED *I/O*

The LED indicates whether the unit is ready for operation.

- [3] **Display** See p. 17, Para. 4.3.
- [4] LED *REM* The LED lights up if the RLC 300 is being remote controlled via the PC.
- [5] LED RANGE HOLD

The LED lights up if the automatic measuring range selection is blocked.

[6] LED CIRCUIT HOLD

The LED lights up if the automatic selection of the equivalent circuit is blocked.

[7] **LED** *LEVEL* The LED lights up if the low level of the measuring signal is switched on.

[8] LED *BIAS* The LED lights up if the polarization voltage is switched on.

[9] F1 button (function button with multiple allocation) FUNC - The button opens the menu FUNC to set the measuring function. ... - The button has different meanings at the menu levels.

[10]	F2 button (funct MODE	 ion button with multiple allocation) The button opens the menu MODE to set the mode of operation of the RLC 300. The button has different meanings at the menu levels. 		
[11]	F3 button (funct SIGNAL	 ion button with multiple allocation) The button opens the menu SIGNAL to set the parameters of the mesuring signal. The button has different meanings at the menu levels. 		
[12]	F4 button (funct MENU 	 ion button with multiple allocation) The button opens the menu MENU to set further parameters of the RLC 300. The button has different meanings at the menu levels. 		
[13]	EXIT/LOCAL b EXIT LOCAL	 utton The button starts the measurement with the current settings from every menu level. On remote control the RLC 300 changes to local control. 		
[14]	Cursor button D	OWN - The cursor is moved downwards in the menu.		
[15]	Cursor button UP☆- The cursor is moved upwards in the menu.			
[16]	ENTER button ENTER	- With this button the new parameter setting is confirmed and the previous menu level is selected.		
[17]	Ground terminal			
[18]	BNC socket - measuring socket Hi			
[19]	BNC socket - measuring socket Hu			
[20]	BNC socket - measuring socket Lu			
[21]	BNC socket - measuring socket Li			
[22]	Input socket of the external polarization voltage (positive measuring terminal)			
[23]	Input socket of the external polarization voltage (negative measuring terminal)			
[24]	Plug of RS-232C interface			
[25]	Plug of GPIB interface			
[26]	Operating voltag The indication sh	ge indication ows which operating voltage is to be used.		
[27]	Fused plug for n	on-heating appliances		

The RLC 300 is protected by a fuse of T100L250V for 230 V~ or T200L250V for 115 V~ net voltage respectively.

[28] Type plate

5.3 Starting

Ge Note	When the RLC 300 is operated remotely via PC the connecting cable of the system interface must be connected before switching on the operating voltage. (See p. 51, Para. 7.1.1 and see p. 53, Para. 7.2.1).
Switching on the RLC 300	1. Connect the RLC 300 [27] with the mains cable to the mains system.
	 2. Press the power switch [1]. The LED <i>I/O</i> [2] lights up and the following message appears on the display [3]:
	< R L C 3 0 0 > V e r s i o n : 1 . 0 1
Starting the initialization test	An internal initialization test starts up. The components and the calibrating data are checked. The following message appears on the display [3]:
	<pre>< RLC300> PowerUp SelfTest</pre>
	The individual test procedures are accompanied by the following messages:
	Testing: UNIT PASSED
	 The variable UNIT stands for the unit which has just been tested: processor (CPU) RAM memory (RAM) ROM memory (EPROM) EEPROM memory (EEPROM) display (DISPLAY) keyboard (KEYBOARD) whole system (SYSTEM)
Fault-free test	On error-free conclusion of the test the following confirmation and current software version appear, e. g.:
	< R L C 3 0 0 > V e r s i o n : 1 . 0 1
P Note	The initialization test can be switched off (See p. 47, Para. 6.5.2.3).
Check of the calibrating data	If the initialization test is switched off the calibrating data of the EEPROM memory are checked only after switching on. On error-free conclusion the following message appears on the display [3]:
	< R L C 3 0 0 > R e a d y !
	In the event of a fault the following message appears on the display [3]:
	<pre><rlc300> Calibration OFF!</rlc300></pre>

Operating state	After fault-free testing the parameters of the following initial state:	of the RLC 300 correspond to
	Measuring the main parameters:	automatic
	Measuring range selection:	automatic
	Selection of the equivalent	
	connection of the measured object:	automatic
	Triggering of the measurements:	automatic
	Frequency of the measuring signal:	1 kHz
	Level of the measuring signal:	NORM (1 V)
	Polarization voltage:	is switched off
	Monitor function:	is switched off
	Averaging function:	is switched off
	Correction of the residual parameters:	is switched off
	Residual parameters:	are deleted
	Tolerance measurement:	is switched off
	Reference and tolerance values:	are deleted
	Interface parameters:	user-defined
	Test to the self-diagnosis:	user-defined

The RLC 300 is in the measuring mode and carries out automatic identification and measurement of the measured object. If a measuring impedance is not connected the following message appears on the display [3], e. g.:

C p : D :	0.31 0.04	рF

Note After switching on the RLC 300 is basically ready to start measurements. But the specified parameters are only fully set after a warm-up time of approx. 20 minutes.

Faulty test

Should a system error occur during the internal test, the RLC 300 interrupts the test until the error is eliminated. The following message appears on the display [3]:

Т	е	s	t	i	n	g	:	UNIT
•	•	•	•	•	•	•	•	ERROR

The variable **UNIT** stands for the unit which has just been tested (See above). If errors which have no direct effect on the function of the RLC 300 occur in the component circuits, the test will continue.

6 Operation of the RLC 300

6.1 Introduction

Keybord	The RLC 300 is operated via eight buttons which are assembled in two rows. The upper four buttons are function buttons F1 to F4 with multiple functions. In response to the state of operation of the RLC 300 and the menu-driven settings, the function buttons perform different tasks (See p. 20, Para. 5.2). The lower four buttons are direct-selection buttons. The cursor buttons I_1 [14] and \hat{T} [15] are used for scrolling with menu-driven settings and the buttons EXIT [13] and ENTER/LOCAL [16] are used to carry out instrument functions quickly.
Menu-driven	After activating the function buttons F1 to F4, menus and also menupoints for settings are opened.
operation via	After opening a menu, the name of the menu is displayed in the top line of the display [3]. The function buttons F1 to F4 have the function as displayed in the bottom line of the display.
display	The cursor buttons \mathfrak{P} [14] and \mathfrak{T} [15] serve to set the desired parameters. The request for using the cursor buttons is signalised in the display [3] with the symbol \mathfrak{P} .
Parameter input	After opening a menu, the measurements are interrupted until the menu is exited either by pressing the EXIT button [13] or by repeatedly pressing the ENTER button [16] (according to the menu level which has been selected).
and	Pressing the EXIT button [13] immediately closes the menu-driven settings and starts the measurement. All parameters which have already been set are activated.
measurement	The ENTER button [16] selects the previous menu level, or measurement is started.

6.2 Measuring Signal Parameters

6.2.1 Frequency of the Measuring Signal

Introduction The frequency of the internal measuring signal can be switched between 50 Hz, 100 Hz, 1 kHz and 10 kHz and thus make optimal measurement results possible when determining the various measuring impedances.

6.2.1.1 Setting the Frequency

- Calling up the menu point **1.** Press the **F3 button SIGNAL** [11] when the RLC 300 is in the measuring mode.
 - The menu for the parameter setting of the measuring signal appears on the display [3].

	Signal	-	-	
FREQ	LVL	В	I	A S

2. Press the F1 button FREQ [9].

- The current value of the measuring frequency appears on the display [3], e. g.:



- **3.** With the help of the **cursor buttons** \mathfrak{P} [14] and \mathfrak{P} [15], set the Changing the parameter desired measuring frequency 50 Hz, 100 Hz, 1 kHz or 10 kHz.
- 4. Change to the menu for the parameter setting of the measuring Completing the signal with the ENTER button [16].
- Starting the 5. Start the measuring mode of the RLC 300 with the EXIT measurement **button** [13].

6.2.2 Level of the Measuring Signal

settings

Measurements with two different levels of the measuring signal are Nominal and actual value level possible with the RLC 300:

- Measuring voltage NORMAL (1 V)
- Measuring voltage LOW (50 mV)

The nominal value of the measuring voltages can be measured at the load-free measuring socket Hi.

The actual value of the voltage via the measured object is always smaller than the nominal value because of the generator's inner resistance (approx. 100Ω).

The actual value of the voltage via the measured object and the actual value of the current flowing through the measured object can be measured and displayed with the help of the monitor function (See p. 44, Para. 6.5.1).

Application of the The LOW level is particularly suitable for measuring semiconductor LOW level components such that the semiconductor transition remains blocked. Furthermore the LOW level is suited to measuring spools with highly permeable cores because the inductance is heavily dependent on the saturation of the core.

6.2.2.1 Setting the Level

Calling up the menu point

- 1. Press the F3 button SIGNAL [11] when the RLC 300 is in the measuring mode.
 - The menu for the parameter setting of the measuring signal appears on the display [3]:

	Signal	
FREQ	LVL	BIAS

- 2. Press the F2 button LVL [10].
 - The current value of the measuring frequency appears on the display [3], e. g.:



Changing the parameter	3. With the help of the cursor buttons ♀ [14] and ☆ [15], set the desired measuring level NORMAL (1 V) or LOW (50 mV).
Completing the settings	4. Change to the menu for the parameter setting of the measuring signal with the ENTER button [16].
Starting the measurement	 5. Start the measuring mode of the RLC 300 with the EXIT button [13]. The active LOW level of the measuring signal is indicated with the LED <i>LEVEL</i> [7].

6.2.3 Polarization Voltage

P Note	Note the connection polarity with applied polarization voltage. There must be no short-circuit between the measuring sockets.
Application	The use of the polarization voltage is particularly suited to measuring electrolytic capacitors and voltage-dependent semiconductor components.
Connection conditions	The polarization voltage is applied internally from a voltage source of approx. 2 V or externally via the input sockets [22] and [23] at the rear panel of the RLC 300. The negative pole of the polarization voltage is at the ground of the RLC 300 and the positive pole of the polarization voltage is at the Hi socket of the RLC 300. When measuring with Kelvin terminals, the positive pole is marked red.

6.2.3.1 Setting the Polarization Voltage

Calling up the	1. Press	the F3	3 button	SIGNAL	[11]	when	the	RLC 300	is	in	the
menu point	measu	ring m	ode.								

- The menu for the parameter setting of the measuring signal appears on the display [3]:

	Signal	
FREQ	LVL	BIAS

2. Press the F4 button BIAS [12].

The current state of the polarization voltage appears on the display [3], e. g.:

Bias:	
Û	OFF

3. With the help of the cursor buttons 𝔅 [14] and 𝔅 [15], change the current state of the polarization voltage:

• **INTERNAL** - The internal dc voltage source of approx. 2 V is switched on.

- **EXTERNAL** An external dc voltage source of 0 to 30 V is connected.
- **OFF** The polarization voltage is switched off.

Changing the

parameter

Completing the settings	4. Change to the menu for the parameter setting of the measuring signal with the ENTER button [16].
Starting the measurement	5. Start the measuring mode of the RLC 300 with the EXIT button [13].
	- The switched polarization voltage is indicated with the LED

6.3 Measuring Functions

Changing the parameter

Completing the

settings

Starting the measurement

6.3.1 Automatic Measurement of the Main Parameters

BIAS [8].

Application Automatic measurement of the impedance parameters allows for the main parameters R, L and C as well as a dominant secondary parameter Q (R, L) or D (C) to be determined. Should you wish to have a different combination of main and secondary parameters, select the specific measurement of the impedance parameters (See p. 28, Para. 6.3.2).

6.3.1.1 Performing the Automatic Measurement

Calling up the	1. Set	the	automatic	measuring	range	selection	(See	p. 37,
menu point	Para	. 6.4.2	2).					

- 2. Press the F1 button FUNC [9] when the RLC 300 is in the measuring mode.
 - The menu for the selection of the measuring functions appears on the display [3]:

I	- unc	tio	n 1	
AUTO	D MA	N M	ON <	>

- **3.** Select the automatic detection and measurement of the main parameters R, L and C by pressing the **F1 button AUTO** [9].
 - The following message appears on the display [3]:

Auto:	RLC

4. Change to the menu for the selection of the measuring functions with the **ENTER button** [16].

5. Start the measuring mode of the RLC 300 with the **EXIT button** [13].

- The format of the measuring results corresponds to the connected measured object Z_X . The magnitude and the sign of the phase shift of the impedance vector (See p. 28, Fig. 6) serve as deciding criteria for determination of the measuring impedance R, L or C.



Fig. 6 Definition of the RLC parameters in the complex plane

6.3.2 Specific Measurement of the Impedance Parameters

Application The specific measurement of the impedance parameters makes the determination of the main and secondary parameters possible in arbitrary combination.

6.3.2.1 Performing the Specific Measurement

Calling up the menu point **1.** Press the **F1 button FUNC** [9] when the RLC 300 is in the measuring mode.

 The menu for the selection of the measuring functions appears on the display [3]:

	F	u	n	С	t	i	0	n	1		-	-
AUT	0		Μ	A	Ν		Μ	ΟN		<	>	

2. Press the F2 button MAN [10].

- On the display [3] appears:

- in the first line the main and secondary parameters wich are set for the measurement, e. g. C - D
- in the second line the menu for the selection of the main parameters, e. g.:

Manua	1:	C - D
R	L	C Z φ

- **3.** Select the desired main parameters R, L, C or $|Z| \phi$ with the **function buttons F1-F4** [9-12].
 - If the main parameter $|Z| \phi$ is selected, the following message appears on the display [3]:

Manual	:		Ζ φ
R	L	С	Ζ φ

 If the main parameter X (R, L oder C) is selected, the menu for the selection of the secondary parameters Y (Q, D, L, C, R) appears in the display [3]:

Manual	:	
Û		X - Y

4. With the help of the **cursor buttons** ↓ [14] and ☆ [15], select the desired secondary parameter **Y** according to Table 8 (See p. 29).

Changing the

parameter

Main parameter X	Secondary parameter Y										
R	Q	D	L, C								
L	Q	D	R								
С	Q	D	R								

Table 8Combinations of	of the	displayed	parameters
------------------------	--------	-----------	------------

Completing the	5. Cha	ange	to	the	menu	for	the	selection	of	the	measuring	function
settings	with	h the	Eľ	NTE	R but	ton	[16]	•				

6. Start the measuring mode of the RLC 300 with the **EXIT button** [13].

 If the selected main parameter of the measurement does not correspond to the measured object, a negative display result can occur.

6.3.3 Tolerance Measurement

Introduction The RLC 300 can determine the absolute (Δ) and relative (δ) deviation of the measuring parameters in relation to a reference value or can carry out a reference measurement with limiting values. The reference and limiting values must be entered before measurement.

6.3.3.1 Input of Reference and Limiting Values

- Introduction When entering the reference and limiting values, the RLC 300 automatically evaluates the set main parameter and sets the corresponding type of reference value which is to be entered. The reference values are saved separately in the RLC 300 for each main parameter. The limiting values are valid for the same types of the reference values.
- Selecting the menu **1.** Press the **F1 button FUNC** [9] when the RLC 300 is in the measuring mode.
 - The menu for the selection of the measuring functions appears on the display [3]:

	F	u	n	С	t	i	0	n	1		-	-
AUT	0		М	A	Ν		М	O N		<	>	

- **2.** Press the **F4 button < >** [12].
 - The second part of the menu for the selection of the measuring functions appears on the display [3]:

-	-		F	u	n	С	t	i	0	n	2	-	-
Т	R	I	М		D	Ε	۷		Ρ	A R		< >	

- 3. Press the F3 button PAR [11].
 - The menu for entering the reference and limiting values appears on the display [3]:

-	Re	f	&	Li	m i	t	s		-
RΕ	F	ΜI	Ν	ΜA	X	D	L	I	М

settings Starting the measurement

6.3.3.1.1 Entering the Reference Value

Preparation	 Set the desired main parameter which serves as the basis for entering the reference value. (See p. 28, Para. 6.3.2). If the automatic measurement of the main parameters is selected the type of the main parameter and the reference value according to the character of the attached measured object is defined. 				
Calling up the menu point	2. Select the menu for entering the reference and limiting values (See p. 29, Para. 6.3.3.1).				
	 3. Press the F1 button REF [9]. The menu for entering the reference value appears on the display [3], e. g.: Ref: 0.000 pF ⁽²⁾ CLR < > MEAS 				
	4. Enter the reference value with the variants a) or b).				
a) Measuring the reference	5a. Connect the measuring impedance, which is to serve as a reference value, to the RLC 300.				
value	 6a. Press the F4 button MEAS [12]. The RLC 300 carries out a measurement. The measuring result is saved as a reference value of the set main parameter and appears on the display [3]. 				
ব্দে Note	If the measured value lies outside the measuring range, the message Overflow appears briefly on the display [3] and no reference value is saved.				
b) Entering the reference value	 5b. With the help of the F2 button ⇐ [10] and F3 button ➡ [11], select the position of the reference value to be changed. If the cursor moves to the left or right outside of the displayed range, the power of the reference value is decreased or increased respectively. 				
	 6b. With the help of the cursor buttons ♀ [14] and ♀ [15], change the value displayed at the position of the cursor. The reference value can be entered in the value range according to Table 9 (See p. 32). 				
P Note	The F1 button CLR [9] has a special function. After pressing this button, the mantissa of the reference value is cleared, but the power is preserved. This simplifies entering reference values of the same power.				
Completing the settings	7. Change to the menu for entering the reference and limiting values				
U	with the ENTER button [16].				

6.3.3.1.2 Entering the Positive and Negative Limiting Values

Preparation	1. Enter the reference value which serves as base for the input of the limiting values (See p. 30, Para. 6.3.3.1.1).			
Selecting the menu	2. Select the menu for entering the reference and limiting values (See p. 29, Para. 6.3.3.1).			
Entering the neg. limiting value	 3. Press the F2 button MIN [10]. The menu for the input of the negative limiting value appears on the display [3], e. g.: 			
	Min: 0.0 <u>0</u> %			
	4. With the help of the F2 button \Leftrightarrow [10] and F3 button \Rightarrow [11], select the position of the limiting value to be changed.			
	 5. With the help of the cursor buttons ↓ [14] and ☆ [15], change the value displayed at the position of the cursor. The limiting value can be entered in the range of values according to the Table 9 (See p. 32). 			
Completing the settings	6. Change to the menu for entering the reference and limiting values with the ENTER button [16].			
Entering the pos. limiting value	 7. Press the F3 button MAX [11]. The menu for the input of the positive limiting value appears on the display [3], e. g.: 			
	Max: 0.0 <u>0</u> % ↓ CLR < >			
	8. With the help of the F2 button \Leftrightarrow [10] and F3 button \Rightarrow [11], select the position of the limiting value to be changed.			
	 9. With the help of the cursor buttons ↓ [14] and ☆ [15], change the value displayed at the position of the cursor. The limiting value can be entered in the range of values according to the Table 9 (See p. 32). 			
Completing the settings	10. Change to the menu for entering the reference and limiting values with the ENTER button [16].			
Starting the measurement	11. Start the measuring mode of the RLC 300 with the EXIT button [13].			
6.3.3.1.3 Entering th	e Limiting Value of the Dissipation Factor			
Preparation	1. Enter the reference value which serves as base for the input of the limiting values (See p. 30, Para. 6.3.3.1.1).			
Selecting the menu	2. Select the menu for entering the reference and limiting values (See p. 29, Para. 6.3.3.1).			

	 3. Press the F4 button DLIM [12]. The menu for entering the limiting value of the dissipation factor appears on the display [3], e. g.: DI im: 0.0000 ① CLR < > MEAS			
	4. Enter the limiting value with the variants a) or b).			
a) Measuring the limiting value	5a. Connect the measuring impedance, which is to serve as a limiting value of the dissipation factor to the RLC 300.			
dissipation factor	 6a. Press the F4 button MEAS [12]. The RLC 300 carries out a measurement. The measurement result is saved as limiting value of the dissipation factor and appears on the display [3]. 			
ক্টে Note	If the measured value is out of the measuring range, the error message Overflow appears on the display [3] briefly. No limiting value is saved.			
b) Entering the limiting value	5b. With the help of the F2 button \Leftrightarrow [10] and F3 button \Rightarrow [11], select the position of the limiting value to be changed.			
of the dissipation factor	 6b. With the help of the cursor buttons ↓ [14] and ☆ [15], change the value displayed at the cursor position. The limiting value can be entered in the range of values according to the Table 9 (See p. 32). 			
Completing the settings	7. Change to the menu for entering the reference and limiting values with the ENTER button [16].			
Starting the measurement	8. Start the measuring mode of the RLC 300 with the EXIT button [13].			

6.3.3.1.4 Range of Values of Reference and Limiting Values

Parameter	Minimum value	Maximum value	
R, Z	0.00 mΩ	199.99 MΩ	
L	0.000 µH	635.51 kH	
С	0.000 pF	399.99 mF	
MIN	0.00 %	- 99.99 %	
MAX	0.00 %	99.99 %	
DLIM	0.0000	9.9999	

 Table 9
 Range of values of reference and limiting values

Note The maximum reference values of the inductance and the capacitance are valid for the measuring frequency of 50 Hz.

6.3.3.2 Performing the Tolerance Measurement

olocal 1 orgonning int				
Preparation	1. Enter the reference value for the corresponding main parameter (See p. 29, Para. 6.3.3.1.1).			
	2. Enter the limiting values for the comparison measurement (See p. 30, Para. 6.3.3.1.2 and see p. 31, Para. 6.3.3.1.3).			
Calling up the menu point	 3. Press the F1 button FUNC [9] when the RLC 300 is in the measuring mode. The menu for the selection of the measuring functions appears on the display [3]: 			
	AUTO MAN MON <>			
	 4. Press the F4 button <> [12]. The second part of the menu for the selection of the measuring functions appears on the display [3]: 			
	Function 2 TRIM DEV PAR <>			
	 5. Press the F2 button DEV [10]. The current setting of the tolerance measurement appears on the display [3], e. g.: 			
	Deviation: ① ABS			
Changing the parameter	 6. With the help of the cursor buttons ↓ [14] and ☆ [15], set the mode of the tolerance measurement: ABS - measurement of the absolute deviation REL - measurement of the relative deviation COMP - comparison measurement 			
6.3.3.2.1 Measuring t	he Absolute Deviation			
Setting the mode of tolerance	1. Select the menu for setting the tolerance measurement (See p. 33, Para. 6.3.3.2).			
measurement	2. With the help of the cursor buttons ↓ [14] and ☆ [15], select the setting ABS.			
Completing the settings	6. Change to the menu for the selection of the measuring functions with the ENTER button [16].			
Starting the measurement	 4. Start the measuring mode of the RLC 300 with the EXIT button [13]. – The displayed value results from the equation: 			
	$\Delta = \mathbf{M} - \mathbf{R}$			

- where: Δ absolute deviation of the measurement
 - M measured value
 - **R** reference value

	 The result is indicated on the display [3] in the following format, e.g.: 				
	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$				
Completing the settings	3. Change to the menu for the selection of the measuring functions with the ENTER button [16].				
Se Note	The correction of the residual parameters of the measuring terminals is taken into account when the processing the measurement.				
6.3.3.2.2 Measuring	the Relative Deviation				
Setting the mode of tolerance	1. Select the menu for setting the tolerance measurement (See p. 33, Para. 6.3.3.2).				
measurement	2. With the help of the cursor buttons ↓ [14] and � [15], select the setting REL .				
Completing the settings	3. Change to the menu for the selection of the measuring functions with the ENTER button [16].				
Starting the measurement	 4. Start the measuring mode of the RLC 300 with the EXIT button [13]. – The displayed value results from the equation: 				
	$\delta = \left(\frac{M}{R} - 1\right) \times 100$				
	 where: δ - relative deviation of the measurement M - measured value R - reference value 				
	- The result is indicated on the display [3] in the following format, e. g.:				
	δ R p : - 0.01 % Q : 0.0002				
In the second se	The correction of the residual parameters of the measuring terminals is taken into account when processing the measurement.				

6.3.3.2.3 Comparison Measurement

Application	The comparison measurement is suited, for example, to sorting same components with similar parameters. The criteria of the comparison measurement are determined with the help of the reference value R
	and the limiting values MIN, MAX and DLIM. (See p. 29, Para. 6.3.3.1).
Setting the mode of tolerance	1. Select the menu for setting the tolerance measurement (See p. 33, Para. 6.3.3.2).
measurement	2. With the help of the cursor buttons ↓ [14] and ☆ [15], select the setting COMP.

Completing the settings	3. Change to the menu for the selection of the measuring functions with the ENTER button [16].				
Starting the measurement	4. Start the measuring mode of the RLC 300 with the EXIT button [13].				
	 In response to the reference value R and the limiting values MIN, MAX the absolute tolerance limits Rmin and Rmax are set in the RLC 300: 				
	$R_{min} = R \times (1 + MIN)$ and $R_{max} = R \times (1 + MAX)$				
	 where: R_{min} - lower tolerance limit R_{max} - upper tolerance limit R - reference value MIN - negative limiting value (relative deviation from the reference value) MAX - positive limiting value (relative deviation from the reference value) 				
	 The result of the comparison measurement is the states LOW, IN, HIGH, which result from the following dependencies: 				
	LOW- for $M < R_{min}$ and $D < DLIM$ IN- for $R_{min} \le M \le R_{max}$ and $D < DLIM$ HIGH- for $M > R_{max}$ and simultaneously $D < DLIM$ - for $M < R_{max}$ and simultaneously $D > DLIM$ - for $M > R_{max}$ and simultaneously $D > DLIM$				
	where:M- measured valueD- dissipation factor of the measured objectDLIM- limit of the dissipation factor				
© P Note	If parameter $DLIM = 0$, it is not considered in the comparison measurement.				
	 The result is indicated on the display [3] in the following format: 				
	Compare X: LOW <				
	Compare X: < IN >				
	or				
	Compare X: > HIGH				
	where: X - type of the main parameter R, L, C, Z				

6.4 Operating Parameters

6.4.1 Selection of the Equivalent Circuit of the Measured Object

Series and
parallelThe measured object generally has a complex character. The
equivalent circuit can be depicted as series or parallel connection of
the real and imaginary components. (See p. 36, Fig. 7).

The RLC 300 uses this approach to determine the measuring parameters.

The equivalent circuit (E circuit) can be set automatically by the RLC 300 or manually by the user.



Fig. 7 Series or parallel connection of the measuring impedance

Automatic selection of the E circuit

With regard to optimum measuring conditions, the unit measures high impedances at constant voltage V_P (parallel connection) and low impedances at constant current I_S (series connection).

After instrument setting, the RLC 300 sets itself to measurements with automatic selection of the equivalent circuit.

Manual selection of the E circuit For evaluation of a specific parameter of the connected measuring impedance, the equivalent circuit must be set. The desired parameter is calculated from the measured parameters with the help of the mathematical relations (See p. 36, Table 10) and displayed.

Measuring function	Series connection (SERIES)		Parallel connection (PARALLEL)		
	R - C	R - L	R - C	R - L	
R	R _s	R _s	R _P	R _P	
L	$-\frac{1}{\omega^2 C_s}$	L _s	$-\frac{1}{\omega^2 C_P}$	L _P	
С	Cs	$-\frac{1}{\omega^2 L_s}$	C _P	$-\frac{1}{\omega^2 L_p}$	
Q	$\frac{1}{\omega R_s C_s}$	$\frac{\omega L_s}{R_s}$	$\omega R_{P}C_{P}$	$\frac{R_{P}}{\omega L_{P}}$	
D	$\omega R_s C_s$	$\frac{R_s}{\omega L_s}$	$\frac{1}{\omega R_{P}C_{P}}$	$\frac{\omega L_{\rm P}}{R_{\rm P}}$	

 $\omega = 2\pi f$, f = measuring frequency

Table 10 Mathematical definition of the measuring parameters
6.4.1.1 Setting the Equivalent Circuit

Calling up the menu point	 Press the F2 button MODE [10] when the RLC 300 is in the measuring mode. The menu for setting the operating mode appears on the display [3]:
	Mode RNG CIR TRIG AVG
	 2. Press the F2 button CIR [10]. The current selection of the equivalent circuit appears on the display [3], e. g.: Circuit: \$
Changing the parameter	 3. With the help of the cursor buttons ↓ [14] and ☆ [15], change the current setting of the equivalent circuit: AUTO - automatic selection of the equivalent circuit SERIES - series connection of the measuring impedance PARALLEL - parallel connection of the measuring impedance
Completing the settings	4. Change to the menu for setting the operating mode with the ENTER button [16].
Starting the measurement	 5. Start the measuring mode of the RLC 300 with the EXIT button [13]. The manual selection of the equivalent circuit is indicated with the LED <i>CIRCUIT HOLD</i> [6].

6.4.2 Measuring Range Selection

Automatic measuring range selection	The RLC 300 is particularly suitable for measurements involving automatic measuring range selection. In order to yield optimum measuring results, the measuring range with the highest measuring resolution is set in response to the connected measuring impedance. After instrument setting, the instrument sets itself for automatic measuring range selection.
Manual measuring range selection	On repeated measurements of the object with approximately the same values and using a polarization voltage it is advisable to use the same measuring range. Here the measuring time is shortened as the automatic selection of the optimum measuring range does not take place. The RLC300 works internally with ten measuring ranges.

6.4.2.1 Setting the Measuring Range 1. Press the F2 button MODE [10] when the RLC 300 is in the Calling up menu point measuring mode. - The menu for setting the operating mode appears on the display [3]: Mode - - - - -- - - -RNG CIR TRIG AVG 2. Press the F1 button RNG [9]. - The current measuring range selection appears on the display [3], e. g.: HOLD Range: AUTO HOLD 3. With the help of function buttons F1 [9] und F2 [10] select the Changing the parameter automatic (AUTO) or manual (HOLD) measuring range selection. - If the automatic measuring range selection is selected, the following message appears on the display [3]: Range: AUTO AUTO HOLD - If the manual measuring range selection is selected, the menu for the measuring range selection appears on the display [3], e. g.: HOLD Range: Û 06 **4.** With the help of the **cursor buttons** \mathbf{J} [14] and $\mathbf{\hat{T}}$ [15], select the desired measuring range from **01** to **10**. Completing the 5. Change to the menu for setting the operating mode with the settings ENTER button [16]. Starting the 6. Start the measuring mode of the RLC 300 with the EXIT measurement **button** [13]. - The manual measuring range selection is indicated with the LED RANGE HOLD [5]. - When setting the measuring range, errors can occur which are displayed with the corresponding messages. (See p. 38, Para. 6.4.2.2). 6.4.2.2 Error Messages **OVERLOAD** The connected measuring impedance causes an overload of the RLC 300 analog component (voltage or current channel) during measurement. The following error message appears on the

** Error: 30 ** Overload

display [3]:

OUT OF RANG

With the manual measuring range selection the connected measuring impedance does not correspond to the set measuring range (See p. 37, Para. 6.4.2). The component, which is used for synchronisation of the measurement is too small. The following error message appears on the display [3]:

_														
*	*	Ε	r	r	0	r	:			2	0		*	*
		Оu	t		ο	f		r	а	n	g	е		

OVERFLOW The value of the connected measuring impedance has exceeded the set (manual measuring range selection) and the maximum (automatic measuring range selection) measuring range. The following error message appears on the display [3], e. g.:

Rp:	10.000 kΩ
D:	Overflow
Rp:	Overflow
D:	0.01

Note If the set measuring range at the manual measuring range selection deviates from the correct measuring range and no error message appears, then the specified measuring accuracies (See p. 14, Para. 4.2.5) for the measuring result do not apply.

6.4.3 Residual Parameters of the Measuring Terminals

or

Residual The measuring signals are tapped off by a four-terminal configuration in order to minimize the influence of the residual parameters. However, a complete elimination of the residual parameters is impossible as the influence of the contact points of the measuring terminals becomes apparent.

The residual parameters can be measured in the case of load-free measuring terminals and also in the case of a short-circuit of the measuring terminals.

Compensation of the residual parameters can be carried out with the help of the correction function.

6.4.3.1 Measuring the Residual Parameters

Selecting the menu

- 1. Press the F1 button FUNC [9] when the RLC 300 is in the measuring mode.
 - The menu for the selection of the measuring functions appears on the display [3]:

Fι	ıncti	on 1	
Αυτο	MAN	MON	< >

2. Press the **F4 button < >** [12].

 The second part of the menu for the selection of the measuring functions appears on the display [3]:

	Fu	ncti	on 2	
TR	Μ	DEV	PAR	< >

3. Press the **F1 button TRIM** [9].

- The menu for the measurement and correction of the residual parameters appears on the display [3]:

Trim		
ΟΡΕΝ	SHORT	CALC

Note After switching off the RLC300 the correction values are deleted.

6.4.3.1.1 Residual Parameters at Load-free Measuring Terminals

Preparation **1.** Switch the measuring terminals to the load-free state. Selecting the 2. Select the menu for the measurement and correction of the residual menu parameters (See p. 39, Para. 6.4.3.1). Measuring the **3.** Press the **F1 button OPEN** [9]. residual - Measurement for all frequencies of the measuring signal is parameters carried out. In the display [3] the actual frequency value appears. The measured residual parameters are saved in the RLC 300. - If the residual impedance of the load-free measuring terminals is smaller than $100 \text{ k}\Omega$ then the measured value is not saved and the following message appears briefly on the display [3]: Trim OPEN: Overflow - After completion of the measurement of the residual parameters the RLC 300 changes to the menu for the measurement and correction of the residual parameters. 6.4.3.1.2 Residual Parameters at Short-circuited Measuring Terminals Preparation **1.** Short-circuit the measuring terminals. - For the measuring adapter with Kelvin terminals, the shortcircuit has to be generated at the outermost ends of the treminals. 2. Select the menu for the measurement and correction of the residual Selecting the menu (See p. 39, Para. 6.4.3.1).

Measuring the residual parameters

3. Press the **F2 button SHORT** [10].

- Measurement is carried out for all frequencies of the measuring signal. In the display [3] the actual frequency value appears. The measured residual parameters are saved in the RLC 300.
 - If the residual impedance of the short-circuited measuring terminals is smaller than 10Ω then the measured value is not saved and the following message appears briefly on the display [3]:

Trim	SHORT:
	Overflow

 After completion of the measurement the RLC 300 changes to the menu for the measurement and correction of the residual parameters.

6.4.3.2 Correcting the Residual Parameters

Application	After measuring the residual parameters of the measuring terminals the measured values are saved in the memory of the RLC 300 and can be used during impedance measurement for the correction of the measuring results.
Calling up the menu point	1. Select the menu for the measurement and correction of the residual parameters (See p. 39, Para. 6.4.3.1).
	 2. Press the F4 button CALC [12]. The current state of the correction function appears on the display [3]: Trim calcul.: DISABLED
Changing the parameter	 3. With the help of the cursor buttons ↓ [14] and ☆ [15], change the current state of the correction function: ENABLED - automatic correction of the residual parameters DISABLED - The correction function is switched off.
Completing the settings	4. Change to the menu for the measurement and correction of the residual parameters with the ENTER button [16].
Starting the measurement	 5. Start the measuring mode of the RLC 300 with the EXIT button [13]. The active correction function is identified in the display [3] at the end of the upper line with the symbol T, e. g.:

6.4.4 Trigger Function

Introduction

The RLC 300 allows for continual and single (manually controlled) triggering of the measurements.

6.4.4.1 Setting the Trigger Mode

Calling up the menu point

- 1. Press the F2 button MODE [10] when the RLC 300 is in the measuring mode.
 - The menu for setting the operating mode appears on the display [3]:

	- Mo	de	
RNG	CIR	TRIG	AVG

2. Press the F3 button TRIG [11].

- The current selection of the triggering appears on the display [3], e. g.:

Т	r	i	g	g	е	r	:
ţ						С	ONTINUOUS

- Changing the parameter 3. With the help of the cursor buttons 𝔅 [14] and 𝔅 [15], change the current setting of the triggering:
 - **CONTINUOUS** continuous triggering of the measurement
 - **SINGLE** single triggering of the measurement
- Completing the
settings4. Change to the menu for setting the operating mode with the
ENTER button [16].

5. Start the measuring mode of the RLC 300 with the **EXIT button** [13].

- With the trigger function **SINGLE** one single measurement is started each time the **ENTER button** [16] is pressed. The end of the previous measurement (measuring result) must be waited for. Otherwise the active measurement is stopped.

6.4.5 Averaging Function

Starting the measurement

Introduction The averaging function allows the measuring result to be displayed with a higher accuracy. Ten measurements are carried out, mathematically evaluated and the end result is displayed.

Application The use of the averaging function is suited for measurements close to the measuring range limits where the measuring results can be unstabler.

6.4.5.1 Switching on/off the Averaging Function

Calling up the menu point

- **1.** Press the **F2 button MODE** [10] when the RLC 300 is in the measuring mode.
 - The menu for setting the operating mode appears on the display [3]:

	-	Мο	d e		
RNG	CI	R	ΤR	IG	A V G

2. Press the F4 button AVG [12].

The current setting of the averaging function appears on the display [3], e. g.:

A v e	rage:	
$\hat{\mathbf{v}}$		1

- 3. With the help of the cursor buttons ♀ [14] and ☆ [15], change the current setting of the averaging function:
 - 1 The averaging function is switched off.
 - **10** The averaging function is switched on.
- **4.** Change to the menu for setting the operating mode with the **ENTER button** [16].
 - **5.** Start the measuring mode of the RLC 300 with the **EXIT button** [13].
 - At the active averaging function the measurement result appears after approx. 3 to 4 s.

Changing the parameter

Completing the settings

Starting the measurement

6.5 Additional Functions

6.5.1 Monitor Function)n
Introduction	The RLC 300 allows mesurement and display of the measuring voltage present at the measured object and the current flowing through the measured object or the polarization direkt voltage connected to the measured object.
Selecting the menu	 1. Press the F1 button FUNC [9] when the RLC 300 is in the measuring mode. The menu for the selection of the measuring functions appears on the display [3]: Image: Constraint of the selection of the measuring functions appears on the display [3]:
	 2. Press the F3 button MON [11]. The current setting of the monitor function appears on the display [3], e. g.:
Changing the parameter	 3. With the help of the cursor buttons ↓ [14] and ↑ [15], change the current setting of the monitor function: V-I - The measuring signal parameters are measured and displayed. BIAS - The polarizing voltage is measured and displayed. OFF - The monitor function is switched off.
6.5.1.1 Measuring and	l Displaying the Measuring Signal Parameters
Application	This function is suitable e.g., for controlling voltage- or current- loading of the measured object.
Calling up the menu point	1. Select the menu for setting the monitor function (See p. 44, Para. 6.5.1).
	 With the help of the cursor buttons ↓ [14] and ☆ [15], select the setting V - I.
Completing the settings	3. Change to the menu for setting the monitor function with the ENTER button [16].
Starting the measurement	 4. Start the measuring mode of the RLC 300 with the EXIT button [13]. The measurement result appears on the display [3] in the following format, e. g.:

6.5.1.2 Measuring and Displaying the Polarization Voltage

Application	With the help of this function, the voltage dependence of the capacitance from semiconductor components can be measured.
Calling up the menu point	1. Select the menu for setting the monitor function (See p. 44, Para. 6.5.1).
	2. With the help of the cursor buttons ♀ [14] and � [15], select the setting BIAS.
Completing the settings	3. Change to the menu for setting the monitor function with the ENTER button [16].
Starting the measurement	 4. Start the measuring mode of the RLC 300 with the EXIT button [13]. The measurement result appears on the display [3] in the following format, e. g.:
	Cp: 10.00 pF Bias: 0.000 V
6.5.2 User Functions	
Contents	The RLC 300 is equipped with a series of special functions which support user-oriented control and measurement.
Selecting the	1. Press the F4 button MENU [12] when the RLC 300 is in the

1. Press the **F4 button MENU** [12] when the RLC 300 is in the measuring mode.

- The main menu appears on the display [3]:

-		-	-		М	е	n	u		-	•	-	-	-
Т	ΝΤ	•	U	S	Ε	R		S	Ε	R	۷	I	С	Ε

2. Press the F2 button USER [10].

- The menu of the user functions appears on the display [3]:

User	Menu	
STO RCL	TEST	LCD

6.5.2.1 Saving the Current Instrument Settings

menu

Application If measurements with certain instrument settings are repeated, there is the possibility of saving up to four parameter configurations in the RLC 300.

Preparation **1.** Set the desired parameter configuration:

- Automatic or specific measurement of the impedance parameters incl. the combination of the main and secondary parameters
- Monitor function
- Correction of the residual parameters of the meas. terminals
- Tolerance measurement incl. the reference and limiting values
- Mode of the meas. range selection incl. the current meas. range
- Selection of the equivalent circuit
- Averaging function
- Frequency of the measuring signal
- Levels of the measuring signal
- Source of the polarization voltage

Calling up the menu point

Changing the

parameter

- 2. Call up the menu of the user functions (See p. 45, Para. 6.5.2).
- **3.** Press the **F1 button STO** [9].
 - The selection of the memories appears on the display [3]:

Store	user	Nr.
0	12	3

- 4. With the help of the function buttons F1-F4 [9-12] select the memory space 0, 1, 2 or 3.
 - If the **memory space is free**, the actual instrument setting is saved. The following message appears on the display [3]:

St	0	r	е			u	s	е	r		Ν	r	Х
	•	•	•	•	•	•		0	Κ	!			

X is the number of the selected memory space. The RLC 300 changes to the menu of the user functions.

- If the **memory space is occupied**, the question if the memory content should be replaced appears on the display [3]:

St	o r	е			u	s	е	r		Ν	r		Х
Rе	w r	i	t	е	?		Y	Е	S		Ν	0	

- **5.a)** Press the **F3 button YES** [11].
 - The current instrument setting is saved. The following message appears on the display [3]:

S	t	ο	r	е			u	s	е	r	Ν	r	Χ
	•	•	•	•	•	•	•		0	Κ!			

The RLC 300 reverts to the menu of the user functions.

- **5.b)** Press the **F4 button NO** [12].
 - The RLC 300 changes to the menu of the user functions without saving.
- 6. Start the measuring mode of the RLC 300 with the EXIT button [13].

Starting the measurement

6.5.2.2 Loading the Saved Instrument Setting

Completing the

settings

Starting the measurement

Calling up the	1. Call up the menu of the user functions (See p. 45, Para. 6.5.2).
menu point	 2. Press the F2 button RCL [10]. – The selection of the memories appears on the display [3]:
	Recall user Nr. 0 1 2 3
Loading the parameter	3. With the help of the function buttons F1-F4 [9-12] select the memory space 0, 1, 2 or 3.
	 If the memory space is occupied, the current instrument setting is loaded. The following message appears on the display [3]:
	Recall user Nr.X OK!
	X is the number of the selected memory space. The RLC 300 reverts to the menu of the user functions.
	 If the memory space is not occupied, the following message appears on the display [3]:
	Recall user Nr.X is not defined!
	The RLC 300 changes to the menu of the user functions.
Starting the measurement	4. Start the measuring mode of the RLC 300 with the EXIT button [13].
6.5.2.3 Switching on/o	off the Initialization Test
Calling up the	1. Call up the menu of the user functions (See p. 45, Para. 6.5.2).
menu point	2. Press the F3 button TEST [11].
	 The current state of the initialization test appears on the display [3]:
	PowerUp SelfTest ① ENABLED

Changing the parameter
3. With the help of the cursor buttons ↓ [14] and ☆ [15], change the current state of the initialization test:
ENABLED - The initialization test is switched on.
DISABLED - The initialization test is switched off.

4. Change to the menu of the user functions with the **ENTER button** [16].

5. Start the measuring mode of the RLC 300 with the **EXIT button** [13].

6.5.2.4 Settings at the Display

-								
Contents	With the RLC 300, it is possible to adjust the brightness and contrast settings of the display according to user preferences.							
Calling up the	1. Call up the menu of the user functions (See p. 45, Para. 6.5.2).							
menu point	 2. Press the F4 button LCD [12]. The menu for setting the display appears on the display [3]: 							
	CONTR BRIGHT							
Changing the contrast	 3. Press the F1 button [9] or F2 button CONTR [10]. – The current contrast setting appears on the display [3], e. g.: 							
	Contrast Adjust: û 90 %							
	4. With the help of the cursor buttons ↓ [14] and ☆ [15], change the current contrast setting in the range of 0 to 100 % in 5 % steps.							
Completing the settings	 Change to the menu for setting the display with the ENTER button [16]. 							
Changing the brightness	 6. Press the F3 button [11] or F4 button BRIGHT [12]. – The current brightness setting appears on the display [3]: 							
	Bright Adjust: û 80 %							
	7. With the help of the cursor buttons ↓ [14] and ☆ [15], change the current brightness setting in the range of 0 to 100 % in 5 % steps.							
Completing the settings	8. Change to the menu for setting the display with the ENTER button [16].							
Starting the measurement	 9. Start the measuring mode of the RLC 300 with the EXIT button [13]. After switching off the RLC 300 the last settings of the display is kept. 							

6.5.3 Service Functions

Contents

Selecting the menu

The RLC 300 contains diagnostic tests for self-diagnosis and special functions for service and calibration work.

- **1.** Press the **F4 button MENU** [12] when the RLC 300 is in the measuring mode.
 - The main menu appears on the display [3]:

	- Men	u	
ΙΝΤ	USER	SERV	ICE

- 2. Press the F3 button [11] or F4 button SERVICE [12].
 - The menu of the service functions appears on the display [3]:

-	S	е	r	v	i	С	е	I	М	е	n	u		-
ΤЕ	S	Т						S	Ρ	Ε	С	I	A	L

6.5.3.1 Self-diagnosis of the RLC 300

P Note	For the successful testing sequence test equipment is necessary.							
Calling up the menu point	1. Call up the menu of the service functions (See p. 48, Para. 6.5.3).							
Starting the self- diagnosis	 2. Press the F1 button TEST [9]. Internal diagnostic test routines are started. After successful completion of the test the RLC 300 returns to the menu of the service functions. 							
Starting the measurement	3. Start the measuring mode of the RLC 300 with the EXIT button [13].							
6.5.3.2 Special Funct	ions of the RLC 300							
Calling up	1. Call up the menu of the service functions (See p. 48, Para. 6.5.3).							
password input	 2. Press the F3 button [11] or F4 button SPECIAL [12]. The field for the input of the password appears on the display [3]: 							
	Password: ↓ < > 000000000							
Entering the password	3. With the help of the F1 button \Leftrightarrow [9] and F2 button \Rightarrow [10], select the position of the password to be changed.							
	4. With the help of the cursor buttons \mathbf{D} [14] and $\mathbf{\hat{T}}$ [15], change the value displayed at the position of the cursor.							
	 5. Press the ENTER button [16] after completion of the password input. The special menu is opened to the authorized user (service technicians) for service and calibration work. 							
Wrong password input	Upon wrong input of the password the following message appears on the display [3] and the RLC 300 changes to the menu of the service functions:							
	Password: Invalid password							

- 6. Press the ENTER button [16].
 - The RLC 300 changes to the measuring mode.

7 Remote Control by Program

(F	Note
- W	NOLC

For remote control of the RLC 300 the connecting cable of the respective system interface GPIB or RS-232C has to be connected before switching on the operating voltage.

7.1 Remote Control via GPIB (IEEE 488.2)

7.1.1 Connection of the RLC 300 to the System

Prerequisite	The connecting cable must correspond to the standard IEEE 488.1 when the RLC 300 is connected to a system with an interface to IEEE 488.1.
Joining the connecting cable	1. Join the connecting cable to the RLC 300 [25] and the system (PC, measuring system, printer).
	2. Screw in tight the connections.
Ge Note	Make sure that the phase of the mains voltage at the RLC 300 and the system is the same, the earth connection was removed and the EMC/ESD regulations are observed.
Switching on the RLC 300	 3. Switch on the RLC 300. After the initialization test the RLC 300 can receive commands.
7.1.2 Selection of the	Interface Type
Selecting the menu	 Press the F4 button MENU [12] when the RLC 300 is in the measuring mode. The main menu appears on the display [3]: INT USER SERVICE Press the F1 button INT [9]. The menu for the configuration of the interface appears on the display [3]:
	Interface TYPE SET
Calling up the menu point	 3. Press the F1 button TYPE [9]. – The current interface type appears on the display [3], e. g.: Interface Type: RS232
Changing the parameter	 4. With the help of the cursor buttons ↓ [14] and ☆ [15], change the interface type: GPIB - The interface GPIB is active. RS-232C - The interface RS-232C is active.
Completing the settings	5. Change to the menu for the configuration of the interface with the ENTER button [16].
Starting the measurement	6. Start the measuring mode of the RLC 300 with the EXIT button [13].

7.1.3 Interface Parameters

Selecting the menu

- **1.** Press the **F4 button MENU** [12] when the RLC 300 is in the measuring mode.
 - The main menu appears on the display [3]:

-		- Men	u	-	-	-	-	-
I	ΝΤ	USER	S E	R	V	I	С	E

- **2.** Press the **F1 button INT** [9].
 - The menu for the configuration of the interface appears on the display [3]:

-	-		I	n	t	е	r	f	а	С	е	-	-	
Т	Y	Ρ	Ε		S	Ε	Т							

3. Press the F2 button SET [10].

The menu for setting the interface parameters appears on the display [3]:

Set	GPIB	
ADDRESS	ΤΟΝ	

7.1.3.1 Setting the GPIB Address

- Calling up the
menu point1. Select the menu for setting the interface parameters (See p. 51,
Para. 7.1.3).
 - 2. Press the F1 button [9] or F2 button ADDRESS [10].
 - The current GPIB address appears on the display [3], e. g.:

GPIB	Address:	
$\hat{\mathbf{U}}$		07

- Changing the
parameter3. With the help of the cursor buttons ↓ [14] and ☆ [15], change
the GPIB address within the range of **00** to **31**.
 - **4.** Change to the menu for setting the interface parameters with the **ENTER button** [16].
 - **5.** Start the measuring mode of the RLC 300 with the **EXIT button** [13].

7.1.3.2 Operation without Control Unit - TON

Application In operating mode TON (TALK ONLY) it is possible to connect a device (printer) in the operating mode LON (LISTEN ONLY) to the RLC 300. With it the reporting of readings is possible.

- Calling up the
menu point1. Select the menu for setting the interface parameters (See p. 51,
Para. 7.1.3).
 - 2. Press the F3 button TON [11].
 - The current state of the operating mode TON appears on the display [3], e. g.:



Changing the **3.** With the help of the cursor buttons \mathfrak{P} [14] and \mathfrak{T} [15], change

Completing the

settings

Starting the

measurement

parameter	 the state of the operating mode TON: ON - The operating mode TON is switched on. OFF - The operating mode TON is switched off.
Completing the settings	4. Change to the menu for setting the interface parameters with the ENTER button [16].
Starting the measurement	 5. Start the measuring mode of the RLC 300 with the EXIT button [13]. After every measurement the measured value is filed in the output buffer and is sent in the following format:
	 <unit> <tx.xetzx><cr><end> to</end></cr></tx.xetzx></unit> <unit> <tyxx.xxxetzx><cr><end></end></cr></tyxx.xxxetzx></unit>
	 where: UNIT - measuring unit of the current measuring function (See p. 70, Para. 7.5.3) E - exponent X - character from 0 to 9 Y - character from 1 to 9 Z - character 0 or 1 T - character +, - or "Blank" CR - character CR (13 dec.) END - end signal LF (10 dec.) + END (EOI true)
P Note	If there is no active device (printer) in operating mode LON connected to the RLC 300, error 171 No listener appears.

7.2 Remote Control via RS-232C

7.2.1 Connection of the RLC 300 to the PC

Prerequisite	Remote control of the RLC 300 with a personal computer (PC) is possible via the serial interface RS-232C. The interface of the personal computer must be configured as described in paragraph 4.4.2 (See p. 17). The connecting cable of the type DTE-DTE must not be longer than 15 m.
Joining the connecting cable	 Join the connecting cable to the RLC 300 [24] and the PC. Screw in tight the connections.
P Note	Make sure that the phase of the mains voltage at the RLC 300 and PC is the same, the earth connection was removed and the EMC/ESD regulations are observed.
Switching on the RLC 300	 3. Switch on the RLC 300. After the initialization test the RLC 300 can receive commands.
7.2.2 Selection of the	Interface Type
Reference	Set the interface type RS-232C (See p. 51, Para. 7.1.2).

7.2.3 Interface Parameters

Selecting the	1.	Press	the	F4	button	MENU [12]	when	the	RLC	300	is	in	the
menu		measu	iring	g mo	de.								

- The main menu appears on the display [3]:

		-	-		Μ	е	n	u		-	-	-	-	-
11	N T		U	S	Ε	R		S	Ε	R	۷	I	С	Ε

- 2. Press the F1 button INT [9].
 - The menu for the configuration of the interface appears on the display [3]:

	I	n	t	е	r	f	а	С	е	-	-
ТҮР	Ε		S	Ε	Т						

- 3. Press the F2 button SET [10].
 - The menu for setting the interface parameters appears on the display [3]:

	S	е	t		R	S		2	3	2		-	-
B D -	R	A	т	Е		Ρ	R	0	Т	0	С	0	L

7.2.3.1 Setting the Baud Rate

Calling up the menu point

- **1.** Select the menu for setting the interface parameters (See p. 53, Para. 7.2.3).
- 2. Press the F1 button [9] or F2 button BD-RATE [10].
 - The current baud rate appears on the display [3], e. g.:

Baud	Rate:	
$\hat{\mathbf{U}}$		9600

- **3.** With the help of the **cursor buttons** ↓ [14] and ☆ [15], change the baud rate (**1200**, **2400**, **4800** or **9600** Bd).
- **4.** Change to the menu for setting the interface parameters with the **ENTER button** [16].
- **5.** Start the measuring mode of the RLC 300 with the **EXIT button** [13].

parameter Completing the

settings

Changing the

Starting the measurement

7.2.3.2 Setting the Transmission Protocol

Calling up the menu point	1. Select the menu for setting the interface parameters an (See p. 53, Para. 7.2.3).
	 2. Press the F3 button [11] or F4 button PROTOCOL [12]. The current setting of the transmission protocol appears on the display [3], e. g.:
	Protocol: ① NONE
Changing the parameter	 3. With the help of the cursor buttons ↓ [14] and ☆ [15], change the setting of the transmission protocol: NONE - communication without transmission protocol RTS/CTS - communication with RTS/CTS protocol
Completing the settings	4. Change to the menu for setting the interface parameters with the ENTER button [16].
Starting the measurement	5. Start the measuring mode of the RLC 300 with the EXIT button [13].

7.2.4 Transmission Protocol

Contents The communication between RLC 300 and PC can be carried out with RTS/CTS protocol or without transmission protocol (NONE).

7.2.4.1 Communication with RTS/CTS Protocol

Data received	Signal RTS=ON
from PC	 RLC 300 can receive data.
	Signal RTS=OFF
	- RLC 300 cannot receive data.
Data transmitted	Signal CTS=ON
to PC	 RLC 300 transmitting data.
	Signal CTS=OFF
	 RLC 300 not transmitting data.

7.2.4.2 Communication without RTS/CTS protocol

Data received from PC	 Signal RTS=ON RLC 300 can always receive data, on overloading of the input buffer the error 181 Inp. Buffer Full is reported.
Data transmitted to PC	Signal CTS=ON – RLC 300 can always transmit data.
P Note	The signal at the output DTR is identical with the signal at the input DSR (The connections DTR and DSR of the plug [24] are connected together).

7.3 Local Control ⇔ Remote Control

Activating the remote control	 Send the command REN via the control unit (PC, measuring system). The RLC 300 is in the REMOTE CONTROL status. This is indicated by the LED <i>REM</i> [4]. Afterwards control of the RLC 300 by the local control elements is not possible (except with the LOCAL button [13]). After the transition to the remote control the current measurement is ended. The RLC 300 is set in the operating mode SINGLE (single triggering of the measurement).
P Note	Block the LOCAL button [13] with the help of the command LLO . Then all the commands of the PC are processed completely.
Activating the local control	 There are several ways of switching from remote control to local control: By transmitting command GTL (Go To Local) from the PC By pressing the LOCAL button [13] at the RLC 300 if the keyboard has not been locked by the command LLO (Local Lock Out) By switching the power switch [1] off and on The button field is ready for use again after the transition for the local control. The LED <i>REM</i> [4] goes out.
Remote control at local control	 The following commands and signals can also be transmitted and received by the control unit when the RLC 300 is on local control: *IDN?, *CLS, *ESR?, *ESE, *ESE?, *STB?, *SRE, *SRE?, ERR?, DER?.
P Note	For local control, transmission of commands and messages is slow. If commands other than those described above are transmitted error 132 Not Ex. in Local appears.

7.4 Messages of the RLC 300 on Remote Control

7.4.1 Description of the Unit Status

Introduction The current status of the operating conditions of the RLC 300 can be interrogated at any time via the EVENT STATUS REGISTER and the STATUS BYTE REGISTER.

7.4.1.1 ESR - EVENT STATUS REGISTER

Reading and deleting the register	 By transmitting the command *ESR? the contents of the ERS register XXX within the range of 0 to 255 are saved in the output buffer and deleted. The ESR register can set on Ø after the following operations (except bit 7): Switching on the RLC 300 Transmitting the command *CLS Changing the interface parameters 			
Contents of the ESR register	 Bit 7: (PON) Power On Operating readiness and interface activities are displayed on 1. Bit 6: (URQ) User Request Is not used, is always set on Ø. Bit 5: (CME) Command Error Is set on 1 at instruction errors. Bit 4: (EXE) Execution Error Is set on 1 at query errors and execution errors. Bit 3: (DDE) Device Dependent Error Device errors are displayed on 1. Bit 2: (QYE) Query Error Is set on 1 at query errors. Bit 1: (RQC) Request Control Is not used, is always set on Ø. Bit 0: (OPC) Operation Complete 			
	Is set on 1 by transmitting the command *OPC .			
7.4.1.1.1 ESE - EVEN	NT STATUS ENABLE REGISTER			
Meaning of the register	 Various statuses and settings of the RLC 300 can be checked. For this the contents of the ESR register are called with the help of a mask. The single bits are compared and evaluated by the following logical equation: ESB = (ESR7 ^ ESE7) × (ESR6 ^ ESE6) × (ESR5 ^ ESE5) × (ESR4 ^ ESE4) × (ESR3 ^ ESE3) × (ESR2 ^ ESE2) × (ESR1 ^ ESE1) × (ESR0 ^ ESE0) The result ESB (Event Summary Bit) is entered in the STB register. 			
Describing the register	The command *ESE <xxx></xxx> offers the possibility of initializing the ESE register with any mask. The value XXX has to be within the range of 0 to 255 . Otherwise the error 134 Val. Out of Range is			

reported.

Reading and deleting the register	 The current contents XXX are saved in the output buffer by transmitting the command *ESE?. The ESE register can set on Ø after the following operations: Switching on the RLC 300 Transmitting the command *ESE 0 Changing the interface parameters 				
7.4.1.2 STB - STATU	S BYTE REGISTER				
Reading and deleting the register	 By transmitting the command *STB? the contents of the STB register XXX within the range of 0 to 255 are saved in the output buffer. The STB register can set on Ø after the following operations (except bit 4 - MAV): Switching on the RLC 300 Transmitting the command *CLS Changing the interface parameters 				
Contents of the STB register	 Bit 7: Is not used, is always set on Ø. Bit 6: (MSS) Master Summary Status Bit Result during checkup of the STB register with a mask (SRE register, see below). Used for setting the RQS Bit. The RQS Bit is dependent on the contents of the STB register and therefore also on the operating requirements (only for GPIB interface – report SRQ). 				
	 (RQS) Request Service Operating requirements (only for GPIB interface). State of the bit is derived from the state of the MSS bit according to IEEE 488.2 and can be read in the serial mode of operation (Serial Poll) according to IEEE 488.1 only as part of the STB registers with the request *STB?. Bit 5: (ESB) Event Summary Bit Result during checkup of the ESR register with a mask (ESE) 				
	 Result during checkup of the LOR register with a mask (LOL register). Bit 4: (MAV) Message Available Is set on 1 if a current message of the RLC 300 is requested at the output buffer. Bit 3: Is not used, is always set on Ø. 				
	 Bit 2: Is not used, is always set on Ø. Bit 1: Is not used, is always set on Ø. Bit 0: Is not used, is always set on Ø. 				
P Note	With remote control via the GPIB interface, the contents of the STB register, including the RQS bit for the control unit in serial mode of operation is accessible according to IEEE 488.1. This is not possible when using the RS-232C interface.				

7.4.1.2.1 SRE - SERVICE REQUEST ENABLE REGISTER

Meaning of the register	 Various statuses and settings of the RLC 300 can be checked. For this the contents of the STB register are called with the help of a mask. The single bits (except SRE bit 6, which is always set on Ø) are compared and evaluated by the following logical equation: MSS = (STB7 ^ SRE7) × (STB5 ^ SRE5) × (STB4 ^ SRE4) × (STB3 ^ SRE3) × (STB2 ^ SRE2) × (STB1 ^ SRE1) × (STB0 ^ SRE0) The result MSS (Master Summary Status) is entered in the STB register.
Describing the register	The command *SRE <xxx></xxx> offers the possibility of initializing the SRE register with any mask. The value XXX has to be within the range of 0 to 255 . Otherwise the error 134 Val. Out of Range is reported.
Reading and deleting the register	 The current contents XXX are saved in the output buffer by transmitting the command *SRE?. The SRE register can set on Ø after the following operation: Switching on the RLC 300 Transmitting the command *SRE 0 Changing the interface parameters
7.4.2 Description of E	Crrors
Contents of the error register	When errors occur in the remote-controlled settings and measurements, they are saved with a code in the error register (See p. 60, Para. 7.4.2.2).
Reading and deleting the register	The contents of the error register can be called and deleted at any time by transmitting the command ERR? . If several errors arise only the error codes of the first and last error are saved. On repeating transmission of the command ERR? the contents of the error codes are filed in the output buffer and initialized (deleted). The initializing of the error register is also started by transmitting the command *CLS (initializing of the state register).
P Note	Before transmission of the command ERR? the interface command DCL has to be transmitted.

7.4.2.1 DER - DEVICE ERROR REGISTER

Meaning of the register	The contents of the DER register specify the device error filed in the error register.			
Reading and deleting the register	 The contents of the register XXX within the range of 0 to 255 are filed in the output buffer by transmitting the command DER?. The DER register can set on Ø after the following commands: Setting of the measuring function Changes of the operating mode Start of the measurements (*TRG, OPEN, SHORT, REF) Initialization of the instrument functions (*RST) 			
ক্টে Note	The DER register is updated after the completion of a measurement (errors 20 and 30) or after interrogation of the measuring parameter (error 10).			
Contents of the DER register	 Bit 7: Is not used, is always set on Ø. Bit 6: Is not used, is always set on Ø. Bit 5: Is not used, is always set on Ø. Bit 4: Is not used, is always set on Ø. Bit 3: Is set on 1 at device error Overflow (error code 10) Bit 2: Is set on 1 at device error Out of Range (error code 20) Bit 1: Is set on 1 at device error Overload (error code 30) Bit 0: Is not used, is always set on Ø. 			
P Note	When a device error occurs the bit 3 (DDE) of the ESR register is set on 1 .			

7.4.2.2 Error Messages

Indication of the error message

The indication of the error messages is dependent on the operating status (local control or remote control) and the type of error (device or interface error):

- On local control interface errors are displayed for only a short time. On remote control of the RLC 300 interface errors are displayed until the contents of the error register are queried or deleted.
- Device errors are displayed until the next measuring result is transmitted or the next interface error appears.

List of Error Messages

Error code	Text of messages	Meaning of text
0	-	Faultless operation
	DEVICE DEPENDENT ERROR	Device error
10	Overflow	Overflow error
20	Out of Range	Exceeding the measuring range
30	Overload	Overload error
	INTERFACE ERROR	Interface error
	Query Error	Query error
111	Unterminated	Is not programmed, but read access
114	Interrupted	Is programmed, but no read access
117	Deadlocked	Is programmed, but is blocked
120	Bad using query	Used query is wrong
	Execution Error	Execution error
131	No Execution	Command cannot be executed
132	Not Ex. in Local	Is not executable at local control
133	No valid data	Data are incorrect
134	Val. Out of Range	Value is out of range
	Command Error	Command error
151	Illegal command	Unknown command
	GPIB Error	Error of the GPIB interface
171	No listener	No instrument is connected in the operating mode TON
	RS 232 Error	Errors of the RS-232C interface
181	Inp. Buffer Full	Input buffer is full

Table 11List of error messages

7.5 List of Commands on Remote Control

7.5.1 General Commands

7.5.1.1 Interface commands

REN (Rem - Transition from local control to remote control

ote)		

	ASCII	Character (dec.)
GPIB	Command according to IEEE 488.1	
RS-232C	HT	9

LLO

- Locking of the LOCAL button [13]

(Local Lock Out)

Locking	or the	LOCILL	outton	[[15]	
				· · · · · · · · · · · · · · · · · · ·	

	ASCII	Character (dec.)
GPIB	Command according to IEEE 488.1	
RS-232C	EM	25

GTL

- Transition from remote control to local control

(Go To Local)

ASCII	Character (dec.)

	ASCII	Character (dec.)
GPIB	Command according to IEEE 488.1	
RS-232C	SOH	1

DCL

- Initializing for the communication protocol of the interface

(Device Clear)

- Resetting or initializing of the partial circuits#

	ASCII	Character (dec.)
GPIB	Command according to IEEE 488.1	
RS-232C	DC4	20

P Note

The command **DCL** has no influence on the functions of the device. These have to be initialized by the general command ***RST**.

GET

- The measurement is started and the measured results are filed in the output buffer of the RLC 300.

	ASCII	Character (dec.)
GPIB	Command according to IEEE 488.1	
RS-232C	BS	8

P Note This command must be at the end of a command line. Otherwise the error 151 **Illegal command** is reported.

7.5.1.2 Initializing the Instrument Settings

*RS1	Г	- Resetting the RLC 300 in the operating st	ate
(Res	et)	Measurement of the main parameters:	automatic
		Measuring range selection:	automatic
		Selection of the equivalent circuit of the measured object:	automatic
		Frequency of the measuring signal:	1 kHz
		Level of the measuring signal:	NORM (1 V)
		Polarization voltage:	is switched off
		Monitor function:	is switched off
		Averaging function:	is switched off
		Correction of the residual parameters:	is switched off
		Residual parameters:	are deleted
		Tolerance measurement:	is switched off
		Reference and tolerance values:	are deleted
æ	Note	After switching on the RLC 300 the comm	ands *RST und *CLS a

oteAfter switching on the RLC 300 the commands *RST und *CLS are
executed automatically and the contents of the ESE and SRE registers
are reset. Bit 7 (PON) of the ESR register is set on 1.

7.5.1.3 Self-Diagnosis of the RLC 300

∗TST?	- Start of internal test and saving of result
(Test)	where: 0 - test is successful
	1 - test is not successful

7.5.1.4 Identification of the RLC 300

*IDN? (Identification)	 Identification <i>digimess</i>,RLC300,X,Y where: X - production number or 0 Y - software version or 0 	
A Nata		

P	Note	The query *IDN? should be written at the end of the command line
		because subsequent data can be lost before transmission. Otherwise
		the error120 Bad using query is reported.

7.5.1.5 Initializing the Error Register

*CLS	- Resetting of ESR and STB register (except bit 4 - MAV)
(Clear Status Byte)	ESE and SRE registers are not deleted.
	– Initializing of the error structure (See p. 59, Para. 7.4.2)

7.5.1.6 Synchronization Commands

*WAI (Waiting)	_	The following commands are executed only after completion of current operation.
*OPC (Operation Complete)	_	After completion of current operation bit 0 (OPC) in the ESR register is set on 1 .

*OPC?	 After completion of current operation the number 1 is saved in the output buffer. 		
C Note	In the RLC 300 all commands are executed sequentially. The execution of the next command starts only when the current operation is ended. While the commands *OPC and *OPC? are executed, the command *WAI does not have any effect.		
7.5.1.7 Query of the ERR?	he Instrument Status – Reading and resetting of the error messages (See p. 59,		

(EIIOI)	Para. 7.4.2)
DER?	– Contents of the DER register are filed in the output buffer.
*ESR? *ESE <xxx> *ESE?</xxx>	– Reading of the ESR register (See p. 57, Para. 7.4.1.1)
*STB? *SRE <xxx> *SRE?</xxx>	- Reading of the STB register (See p. 58, Para. 7.4.1.2)

7.5.2 Instrument Settings and Messages

7.5.2.1 Frequency of the Measuring Signal

FREQ <xx></xx>	 Frequency setting [Hz] with the numeric argument: 50, 100, 1000 orr 10000 (in the free format) The value is rounded up.
P Note	If the value is out of range the error 134 Val. Out of Range is reported.
FREQ?	 The set frequency value [Hz] is filed in the output buffer with the following format: HZ 50, HZ 100, HZ 1000 or HZ 10000
7.5.2.2 Levels of the	Measuring Signal
LEVEL_NORM	- Level setting [V] on 1 V (NORM)

- LEVEL_LOW Level setting [V] on 50 mV (LOW)
- LEVEL? The current setting of the output level is filed in the output buffer with the following format:
 - LEVEL_NORM (1 V) or LEVEL_LOW (50 mV)

7.5.2.3 Polarization Voltage

BIAS_OFF	_	The polarization voltage at the measuring sockets is switched off.
BIAS_INT	_	The internal polarization voltage at the measuring sockets is switched on.
BIAS_EXT	_	The external polarization voltage at the measuring sockets is switched on.
BIAS?	_	 The current state of the polarization voltage at the measuring sockets is filed in the output buffer: BIAS_OFF, BIAS_INT or BIAS_EXT

7.5.2.4 Automatic Measurement of the Main Parameters

AMODE?	_	The current state of the automatic measurement of the main parameters is filed in the output buffer: • AMODE_ON or AMODE_OFF
AMODE_OFF	_	The automatic measurement of the main parameters is switched off.
AMODE_ON	_	The automatic measurement of the main parameters is switched on.

7.5.2.5 Specific Measurement of the Impedance Parameters

MODE_RQ	_	Resistance measurement $[\Omega]$ and measurement of the quality of the measuring impedance [-].
MODE_RD	_	Resistance measurement $[\Omega]$ and measurement of the dissipation factor of the measuring impedance [-].
MODE_LR	—	Inductance measurement [H] and resistance measurement $[\Omega]$.
MODE_LQ	_	Inductance measurement [H] and measurement of the quality of the measuring impedance [-].
MODE_LD	_	Inductance measurement [H] and measurement of the dissipation factor of the measuring impedance [-].
MODE_CR	_	Capacitance measurement [F] and resistance measurement [Ω].
MODE_CQ	_	Capacitance measurement [F] and measurement of the quality of the measuring impedance [-].
MODE_CD	_	Capacitance measurement [F] and measurement of the dissipation factor of the measuring impedance [-].
MODE_ZFI	_	Measurement of the measuring impedance $[\Omega]$ and of the phase shift [deg].
MODE?	_	At the specific measurement of the impedance parameters the current combination of the main and secondary parameters is filed in the output buffer: • MODE_RQ, MODE_RD, MODE_ZFI

7.5.2.6 Automatic Sel	ection of the Equivalent Circuit of the Measured Object
ACIRC_ON	 The automatic selection of the equivalent circuit is switched on. The LED CIRCUIT HOLD [6] goes out.
ACIRC_OFF	 The automatic selection of the equivalent circuit is switched off. The current equivalent circuit is fixed. The LED <i>CIRCUIT HOLD</i> [6] shines.
ACIRC?	 The current state of the automatic selection of the equivalent circuit is filed in the output buffer: ACIRC_ON or ACIRC_OFF

7.5.2.7 Manual Selection of the Equivalent Circuit of the Measured Object

CIRC_SER	_	The series equivalent circuit of the measured object is set. The LED <i>CIRCUIT HOLD</i> [6] shines.
CIRC_PAR	_	The parallel equivalent circuit of the measured object is set. The LED <i>CIRCUIT HOLD</i> [6] shines.
CIRC?	_	The current setting of the equivalent circuit of the measured object is filed in the output buffer with the following format: • CIRC_SER or CIRC_PAR

7.5.2.8 Automatic Measuring Range Selection

ARANGE_ON	_	The automatic measuring range selection is switched on. The LED <i>RANGE HOLD</i> [5] goes out.
ARANGE_OFF	_	The automatic measuring range selection is switched off. The current measuring range is kept. The LED <i>RANGE HOLD</i> [5] shines.
ARANGE?	_	The current state of the automatic measuring range selection is filed in the output buffer with the following format: • ARANGE_ON or ARANGE_OFF

7.5.2.9 Manual Measuring Range Selection

RANGE <xx></xx>	 Manual measuring range selection in the range of 1 bis 10 (in the free format). The value is rounded up. The LED <i>RANGE HOLD</i> [5] shines. 		
P Note	If the value is out of range the error 134 Val. Out of Range is reported.		
RANGE?	 The oriented measuring range is filed in the output buffer with the following format: 1, 2, 3, 10 		

7.5.2.10 Residual Parameters of the Measuring Terminals			
OPEN	 Measurement of the residual parameters at load-free measuring terminals 		
SHORT	 Measurement of the residual parameters at short-circuited measuring terminals 		
TRIM_ON	– The correction of the measuring parameters is switched on.		
TRIM_OFF	- The correction of the measuring parameters is switched off.		
TRIM?	 The current state of the correction of the measuring parameters is filed in the output buffer with the following format: TRIM_ON or TRIM_OFF 		
7.5.2.11 Monitor Fur	nction		
MON_OFF	 The monitor function is switched off. 		
MON_VI	 The voltage at the measured object or the current passing through the measured object is measured and displayed. 		
MON_BIAS	- The polarization voltage at the measuring sockets (BIAS) is measured and displayed.		
MON?	 The current setting of the monitor function is filed in the output buffer with the following format: MON OFF. MON VI or MON BIAS 		
7.5.2.12 Averaging fi	inction		
AVG <xx></xx>	 Setting of the averaging function with the numeric argument (in the free format): 1 - The averaging function is switched off. 10 - The averaging function is switched on. The value is rounded up. 		
ৰ্ট্ট Note	If the value is out of range the error 134 Val. Out of Range is reported.		
AVG?	 The current state of the averaging function is filed in the output buffer with the following format: 1 or 10 		
7.5.2.13 Tolerance M	leasurement		
DEV_OFF	 The tolerance measurement is switched off. 		
DEV_ABS	 The measurement of the absolute deviation in relation to a reference value is switched on. 		
DEV_REL	 The measurement of the relative deviation in relation to a reference value is switched on. 		
DEV_COMP	- The comparison measurement is switched on.		
DEV?	 The current state of the tolerance measurement is filed in the output buffer with the following format: DEV_OFF, DEV_ABS, DEV_REL or DEV_COMP 		

Input of the Reference and Tolerance Values

REF	- An automatic measurement of the connected measuring impedance is started and the measuring result is saved as a reference value. The type of reference value is set in accordance with the value of the measured main parameter.		
REF_R <xx></xx>	 The numeric argument is set as a reference value for the resistance measurement. The valid range of values [Ω] is from 0.01E-3 to 199.99E6 (in the free format). The value is rounded up. 		
REF_L <xx></xx>	 The numeric argument is set as a reference value for the inductance measurement. The valid range of values [H] is from 0.001E-6 to 635.51E3 (in the free format). The value is rounded up. 		
REF_C <xx></xx>	 The numeric argument is set as a reference value for the capacitance measurement. The valid range of values [F] is from 0.001E-12 to 399.99E-3 (in the free format). The value is rounded up. 		
REF_Z <xx></xx>	 The numeric argument is set as a reference value for the impedance measurement. The valid range of values [H] is from 0.01E-3 to 199.99E6 (in the free format). The value is rounded up. 		
COMP_MIN <xx></xx>	 The numeric argument is set as a lower tolerance limit for the comparison measurement. The valid range of values [%] is from 0.00 to -99.99 (in the free format). The value is rounded up. 		
COMP_MAX <xx></xx>	 The numeric argument is set as an upper tolerance limit for the comparison measurement. The valid range of values [%] is from 0.00 to 99.99 (in the free format). The value is rounded up. 		
COMP_DLIM <xx></xx>	 The numeric argument is set as the limit of the dissipation factor for the comparison measurement. The valid range of values [-] is from 0.0000 to 9.9999 (in the free format). The value is rounded up. 		
P Note	When the averaging function is active the resolution of the displayed values increases by a factor of ten. If a value is out of range the error 134 Val. Out of Range is reported.		

Query of the Reference and Tolerance Values

REF_R?	 The set reference value for the resistance measurement is filed in the output buffer with the following format: OHM <tx.xetzx> to OHM <tyxx.xxetzx> where: E - exponent X - character from 0 to 9 Y - character from 1 to 9 Z - character 0 or 1 T - character +, - or "Blank" </tyxx.xxetzx></tx.xetzx>
REF_L?	 The set reference value for the inductance measurement is filed in the output buffer with the following format: H <tx.xetzx> to H <tyxx.xxxetzx></tyxx.xxxetzx></tx.xetzx>
REF_C?	 The set reference value for the capacitance measurement is filed in the output buffer with the following format: F <tx.xetzx> to F <tyxx.xxxetzx></tyxx.xxxetzx></tx.xetzx>
REF_Z?	 The set reference value for the inpedance measurement is filed in the output buffer with the following format: OHM <tx.xetzx> to OHM <tyxx.xxetzx></tyxx.xxetzx></tx.xetzx>
COMP_MIN?	 The set lower tolerance limit for the comparison measurement is filed in the output buffer with the following format: PCT <tx.xxe+00> to PCT <tyx.xxe+00></tyx.xxe+00></tx.xxe+00>
COMP_MAX?	 The set upper tolerance limit for the comparison measurement is filed in the output buffer with the following format: PCT <tx.xxe+00> to PCT <tyx.xxe+00></tyx.xxe+00></tx.xxe+00>
COMP_DLIM?	 The set limit of the loss faktor for the comparison measurement is filed in the output buffer with the following format: <tx.xxxxe+00></tx.xxxxe+00>
7.5.2.14 Trigger Fund	ction
*TRG	 The measurement is started and the measured values are filed in the output buffer of the RLC300.
7.5.2.15 Saving and I	Loading of the Instrument Setting
*SAV <x></x>	 The current instrument setting is filed in the memory space of <x>.</x> The numeric argument is valid within the range of 0 to 3 (in the free format). The value is rounded up.
*RCL <x></x>	 The instrument setting is loaded from the memory <x>.</x> The numeric argument is valid within the range of 0 to 3 (in the free format). The value is rounded up.
P Note	If the value is out of range the error 134 Val. Out of Range is reported. If no value is available, the error 133 No valid data is reported.

7.5.3 Transmitting the Results

7.5.3.1	Measurement of the Main Parameters
R?	 The real resistance of the measured impedance is filed in the output buffer with the following format: OHM <tx.xetzx> to OHM <tyxx.xxxetzx> where: E - exponent X - character from 0 to 9 Y - character from 1 to 9 Z - character 0 or 1 T - character +, - or "Blank" </tyxx.xxxetzx></tx.xetzx>
L?	 The inductance of the measured impedance is filed in the output buffer with the following format: H <tx.xetzx> to H <tyxx.xxxetzx></tyxx.xxxetzx></tx.xetzx>
C?	 The capacitance of the measured impedance is filed in the output buffer with the following format: F <tx.xetzx> to F <tyxx.xxxetzx></tyxx.xxxetzx></tx.xetzx>
Z?	 The measured impedance is filed in the output buffer with the following format: OHM <tx.xetzx> to OHM <tyxx.xxxetzx></tyxx.xxxetzx></tx.xetzx>
FI?	 The phase displacement of the measured impedance is filed in the output buffer with the following format: DEG <tx.xxe+00> to DEG <tyxx.xxe+00></tyxx.xxe+00></tx.xxe+00>
Q?	 The quality factor of the measured impedance is filed in the output buffer with the following format: <tx.xxxe+00> to <t1xxe+00></t1xxe+00></tx.xxxe+00>
D?	 The dissipation factor of the measured impedance is filed in the output buffer with the following format: <tx.xxxxe+00> to <tx.xxxxe+00></tx.xxxxe+00></tx.xxxxe+00>

7.5.3.2 Tolerance Measurement

েল Note	Before transmitting the following commands, a given function mode of tolerance measurement must be set. Otherwise error 131 No Execution is reported.
DEV_R?	 The deviation of the real resistance of the measuring impedance in relation the reference value is filed in the output buffer.
DEV_L?	 The deviation of the inductance of the measuring impedance in relation the reference value is filed in the output buffer.
DEV_C?	 The deviation of the capacitance of the measuring impedance in relation the reference value is filed in the output buffer.
DEV_Z?	- The deviation of the measuring impedance in relation the reference value is filed in the output buffer.

Measurement of the absolute deviation	 The result has the same format as that which is transmitted when measuring the main parameters R?, L?, C? or Z? (See p. 70, Para. 7.5.3).
Measurement of the relative deviation	 The result has the format: PCT <tx.xxe+00> to PCT <tyxx.xxe+00> where: E - exponent</tyxx.xxe+00></tx.xxe+00> X - character from 0 to 9 Y - character from 1 to 9 T - character +, - or "Blank"
Comparison measurement	 The result has the format: <tx> where: -1 - result for LOW 0 - result for IN 1 - result for HIGH </tx>

7.5.3.3 Measuring Parameters at Active Monitor Function

ৰ্জ্ট Note	Before transmitting the following commands an arbitrary monitor function must be set. Otherwise the error 131 No Execution is reported.	
MON_V?	 The measuring voltage at the measured object is filed in the output buffer with the following format: V <tx.xxxetzx> to V <txxx.xetzx> where: E - exponent X - character from 0 to 9 Z - character 0 or 1 T - character +, - or "Blank"</txxx.xetzx></tx.xxxetzx> 	
MON_I?	 The current passing through the measured object is filed in the output buffer with the following format: A <tx.xetzx> to A <tx.xxetzx></tx.xxetzx></tx.xetzx> 	
MON_B?	 The polarization voltage connected at the measuring terminals is filed in the output buffer with the following format: V <tx.xxxe+00> to V <tyx.xxxe+00> where: E - exponent</tyx.xxxe+00></tx.xxxe+00> X - character from 0 to 9 Y - character from 1 to 9 T - character +, - or "Blank" 	
P Note	If the setting of the RLC 300 is changed during the request for the measuring parameter and thus if no measurement can be started, error 133 No valid data appears.	

7.6 Programming Notes

Command line

Single commands can be written one after the other in one command line, the length of which must not exceed 64 characters. In case errors occur, the command sequence is ignored and error 181 **Inp. Buffer Full** is indicated.

Separator characters

A separator character has to be between the single commands (PC \rightarrow RLC 300) or messages (RLC 300 \rightarrow PC):

	ASCII	Character (dec.)
GPIB, RS-232C	;	59

End characters

An end character is at the end of every command line.

■ During transmission of commands (PC → RLC 300):

	ASCII	Character (dec.)
GPIB	"Last character"	"Last character" + END (EOI true)
	LF	10
	LF	10 + END (EOI true)
RS-232C	LF	10

• During receiving of messages (RLC $300 \rightarrow$ PC):

	ASCII	Character (dec.)
GPIB	LF	10 + END (EOI true)
RS-232C	CR+LF	13 + 10

Parameter separator characters Certain commands or messages may contain parameters or results which are separated from the command by a parameter separator characters.

• During transmission of commands (PC \rightarrow RLC 300):

	ASCII	Character (dec.)
GPIB	SP	32
	NUL to HT	0 to 9
	VT to US	11 to 31
RS-232C	SP	32

• During receiving of messages (RLC $300 \rightarrow$ PC):

	ASCII	Character (dec.)
GPIB, RS-232C	SP	32
7.7 Program Examples (Q Basic)

7.7.1 Remote Control via Interface GPIB

```
110 REM THE EXAMPLE IN Q BASIC OF USING RLC 300
120 REM WITH GPIB BOARD AT-GPIB/TNT AND SOFTWARE NI-488.2(NI)
130 REM Its GPIB primary address is 7.
140 REM Instrument settings - frequency: 10 kHz
150 REM
                           - level: LOW
160 REM
                           - mode: C-D
170 REM
                           - monitor: V-I
180 REM Merge this code with DECL.BAS (when using NI-488.2)
200 CLS
210 REM *** Setup interface AT-GPIB/TNT ***
220 DIM ADDRLIST%(31):ADDRLIST%(0)=7:ADDRLIST%(1)=NOADDR%
230 BDINDEX%=0:PAD%=7
240 CALL SENDIFC (BDINDEX%)
250 REM
260 REM *** Setup RLC 300 ***
270 CALL ENABLEREMOTE (BDINDEX%, ADDRLIST%(0))
280 CALL DEVCLEAR(BDINDEX%, PAD%)
290 WRT$="*RST;*CLS"
300 CALL SEND (BDINDEX%, PAD%, WRT$, NLEND%)
310 REM
320 REM *** Measuring signal settings (frequency, level) ***
330 WRT$="FREQ 10000;LEVEL_LOW"
340 CALL SEND (BDINDEX%, PAD%, WRT$, NLEND%)
350 REM
360 REM *** Mode settings ***
370 WRT$="MODE CD;MON VI"
380 CALL SEND (BDINDEX%, PAD%, WRT$, NLEND%)
390 REM
400 REM *** Start of measurements ***
410 WRT$="*TRG;C?;D?;MON V?;MON I?"
420 CALL SEND (BDINDEX%, PAD%, WRT$, NLEND%)
430 REM
440 REM *** Receive response message ***
450 RD$=SPACE$(100)
460 CALL RECEIVE (BDINDEX%, PAD%, RD$, STOPEND%)
470 CLS:PRINT "Response message: ",RD$
480 REM
490 REM *** Setup RLC 300 and set local mode ***
500 WRT$="*RST;*OPC?"
510 CALL SEND (BDINDEX%, PAD%, WRT$, NLEND%)
520 RD$=SPACE$(20)
530 CALL RECEIVE (BDINDEX%, PAD%, RD$, STOPEND%)
540 REM
550 CALL ENABLELOCAL (BDINDEX%, ADDRLIST%(0))
560 REM
570 REM *** Disable the software and hardware ***
580 V%=0
590 CALL IBONL (BDINDEX%, V%)
600 END
```

7.7.2 Remote Control via Interface RS-232C

```
110 ' THE EXAMPLE IN MICROSOFT Q BASIC
120 ' OF USING RLC 300 WITH RS232C INTERFACE
130 ' Serial port is com2 and baud rate is 9600
140 ' Instrument settings - output frequency:
                                              10 kHz
150 '
                        - output level:
                                              TIOM
160 '
                        - parameter indication: C-D
170 '
                        - monitor function:
                                              V-I
190 '
200 CLS
210 '
220 '**** Setup interface ****
230 IDCL$ = CHR$(20): IREN$ = CHR$(9): ILLO$ = CHR$(25):
   IGTL$ = CHR$(1)
240 '
250 '**** Opening communication file ****
260 OPEN "COM1:9600,n,8,1,CS15000,LF" FOR RANDOM AS #1
270 '
280 '**** Setup RLC 300 ****
290 PRINT #1, IDCL$; IREN$; ILLO$; "*RST;*CLS"
300 '
310 '**** Measuring signal settings (frequency, level) ****
320 PRINT #1, "FREQ 10000; LEVEL LOW"
330 '
340 '**** Mode settings ****
350 PRINT #1, "MODE_CD;MON_VI"
360 '
370 '**** Start of measurements ****
380 PRINT #1, "TRG;C?;D?;MON V?;MON I?
390 '
400 '**** Receive response message
410 INPUT #1,A$
420 PRINT "Response message:";A$
430 '
440 '**** Setup RLC 300 and set local mode****
450 PRINT #1, "*RST;*OPC?"
460 INPUT #1, A$
470 PRINT #1, IGTL$
480 '
490 '**** Close statement ****
500 CLOSE #1
510 '
520 END
```

8 Maintenance

P Warning!	The RLC 300 must be separated from all power sources before maintenance work is carried out and before parts or fuses are repaired or replaced.
Care	Only use a soft wet rag with some soap suds or a soft rinse liquid for cleaning. Avoid acrid cleanser and solvents.
Maintenance	The RLC 300 does not require special maintenance if it is used and handled correctly. Service work should only be done by trained personnel. In case of repairs it is vital to ensure that the design features of the RLC 300 are not changed, resulting in a reduction in operational safety, and that replacement parts match the original ones and are installed properly (original state).

9 Appendix

9.1 List of all Instrument Messages

				<	R	L	С	3	0	0	>			
					R	е	а	d	у	!				
				<	R	L	С	3	0	0	>			
С	а	L	i	b	r	а	t	i	ο	n		ο	F	F !
				<	R	L	С	3	0	0	>			
Р	0	w	е	r	U	b	-	S	e	Ī	f	т	е	s t
-	<u> </u>		-	-	_	г		_	-	-	-	-	-	
т	e	S	t	i	n	α	•		U	Ν	T	т		
•	č	Ŭ	•	•		э	•		P	Δ	s	s	F	D
-	•	•	•	•	•	•	•		•	-	-	-	_	_
т	•	e	+	;	n	0			IJ	N	1	т		
•	e	э	Ľ	•		y	•		F	R	ч Р	0	R	
•	•	•	•	•	•	•	•		E	n	N	0	n	
—		-	-	~	_	~	_			-	_	•	-	V
	<	ĸ	L	C	3	0	0	>		ĸ	E	A	D 4	Y
		V	е	r	S	1	0	n	:	1	•	U	1	
Ρ	а	S	S	w	0	r	d	:						Û
Ι	n	V	а	I	i	d		р	а	S	S	w	0	r d
S	t	ο	r	е		u	s	е	r		Ν	r	•	Х
•									Ο	κ	!			
-		-												
S	t	0	r	е		u	s	е	r		N	r		Х
S R	t e	o w	r r	e i	t	u e	s ?	e	r Y	e	N s	r	N	X o
S R	t e	o w	r r	e i	t	u e	s ?	e	r Y	e	N s	r	N	X o
S R R	t e e	o w c	r r a	e i	t	u e	s ? u	e s	r Y e	e r	N s	r N	N	X o . X
S R R	t e e	o w c	r r a	e i I	t 1	u e	s ? u	e s	r Y e O	e r K	N s	r N	N	X o . X
S R R	t e	o w c	r r a	e i I	t 	u e	s ? u	e s	r Y e O	e r K	N s	r N	N r	X o . X
S R R	t e	0 W C	r a	e i	t 1	u e	s ? u	e s s	r Y O	e r K r	N s	r N	N r	X o . X . X
S R R i	t e e s	0 W C	r r a N	e i	t T	u e	s ? u	e s i	r Y e O	e r K r i	N s !	r N e	· N r d	x o . X . X

- Version of the firmware
- Warning with fault characteristics (See p. 22, Para. 5.3)
- Internal test starts
- Faultless test, UNIT describes the just tested unit (See p. 22, Para. 5.3)
- Error during test, UNIT describes the just tested unit (See p. 22, Para. 5.3)
- Operational readiness of the instrument
- Invalid password (See p. 50, Para. 6.5.3.2)
- Invalid password (See p. 50, Para. 6.5.3.2)
- Inquiry at the saving of the instrument setting No. X, if the storage is occupied (See p. 45, Para. 6.5.2.1)
- Loading the instrument setting No. X
- The instrument setting No. X is not defined (See p. 46, Para. 6.5.2.2)

9.2 Declaration of Conformity

digimess	Declaration o	CE							
Der Hersteller/Importeur The manufacturer/importer Le producteur/importateur Anschrift / Address / Adresse		digimess Instruments Test- und Meßsysteme GmbH Test and Measuring Systems GmbH Würzburger Straße 150 90766 Fürth Germany							
erklärt hiermit e declare under t	erklärt hiermit eigenverantwortlich, daß das Produkt: declare under their sole responsibility that the product / déclare, que le produit:								
Bezeichnung / Na	me / Description	Programmierbares automatisches RLC-Meter Programmable automatic RLC Meter RLC-mètre automatique programmable							
Type / Model / Typ	pe	RLC 300							
Bestell-Nr. / Order	-No. / N ^o de réf.	H.UC 35-00							
folgenden Normen entspricht: is in accordance with the following specifications / correspond aux normes suivantes:									
		DIN EN 61010-1							
		DIN EN 50081-1, DIN EN 50081-2							
		EN 55011, EN 55022 Class B							
Das Produkt erfüllt somit die Forderungen folgender EG-Richtlinien: Therefore the product fulfils the demands of the following EC-Directives: Le produit satisfait ainsi aux conditions des directives suivantes de la CE:									
	73/23/EWG	Richtlinie betreffend elektrische Betriebsmittel zur Verwendung innerhalb bestimmter Spannungsgrenzen Directive relating to electrical equipment designed for use within certain voltage limits Directive relatives au matériel électrique destiné à être employé dans certaines limites de tension							
89/336/EWG		Richtlinie über die elektromagnetische Verträglichkeit Directive relating to electromagnetic compatibility Directive relatives à la compatibilité électromagnétique							
	Fürth, 23.1.98	Henninger Leiter Qualitätsmanagement Q-Manager / Directeur Contrôle de Quali	ité						